

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>Cities Service Oil Company</b>	8. Farm or Lease Name <b>O'Brien G</b>
3. Address of Operator <b>P. O. Box 69 - Hobbs, New Mexico 88240</b>	9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>0</b> , <b>660</b> FEET FROM THE <b>South</b> LINE AND <b>1980</b> FEET FROM THE <b>East</b> LINE, SECTION <b>35</b> TOWNSHIP <b>8s</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Twin Lakes San Andres</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3940 DF</b>	12. County <b>Chaves</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

RECEIVED

This well was plugged and abandoned in the following manner:

1. Loaded hole w/mud laden fluid.
2. Displaced 30 sx. plug across San Andres 2640-2280.
3. Cut 4 1/2" casing at 1900' and set 30 sx. cement plug 1/2 in and 1/2 out 4 1/2" casing stub.
4. Set 30 sx. cement plug across top of Queen formation 1455-1355.
5. Displace 30 sx. cement plug 1/2 in and 1/2 out of bottom of 8 5/8 surface pipe 464'-364'.
6. Set sx. cement plug in top of 8 5/8" surface pipe from ground level to 30' and set 4" pipe dry hole marker.
7. Cleaned location of all equipment and debris, filled pits and leveled location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED  
**D. ROBERTSON**

SIGNED \_\_\_\_\_ TITLE **District Clerk** DATE **November 13, 1968**

APPROVED BY \_\_\_\_\_ TITLE **OIL AND GAS INSPECTOR** DATE **11/13/68**

CONDITIONS OF APPROVAL, IF ANY: