

NO. OF COPIES RECEIVED	5
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	3

RECEIVED

NEW MEXICO OIL CONSERVATION COMMISSION
JAN 5 1973

O. C. C.
ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. K-4085
7. Unit Agreement Name
8. Farm or Lease Name AMOCO STATE
9. Well No. 1
10. Field and Pool, or Wildcat Wildcat
12. County Chaves

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER DRY HOLE
2. Name of Operator AZTEC OIL & GAS COMPANY
3. Address of Operator P. O. Box 837, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER P 660 FEET FROM THE South LINE AND 660 FEET FROM THE East LINE, SECTION 16 TOWNSHIP 8-S RANGE 29-E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3985 DF

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was plugged and abandoned in the following manner:

1. Loaded hole with mud laden fluid.
2. Set 100' cement plug at 2850-2950' (Slaughter).
3. Set 100' cement plug at 1000-1100' (Yates).
4. Set 100' cement plug in and out of Surface Casing(300-400').
5. Set 25' cement plug in top of surface casing with proper Dry Hole Marker.
6. Cleared and leveled location.

csg. left in hole 8 5/8" - 345 - Circ.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED **original signed by LESTER L. DUKE** TITLE **District Superintendent** DATE **January 4, 1972**

APPROVED BY *[Signature]* TITLE **OIL AND GAS INSPECTOR** DATE **MAR 22 1973**

CONDITIONS OF APPROVAL, IF ANY: