

Stevens Operating Co.
O'Brien DQ # 2
Sec. 30-7-29-N

1. Spot a 35 sx. plug at 2532' WOC and tag plug .
2. Load hole with salt-gel mud at 25 lb. per bbl.of brine water up to 400'.
3. Pull up hole with tbg.to 400'and fill csg. to surface with cement.
4. Set PA marker, clean and level location.