

Operator McKays Oil Corp
 Well Wolfcamp #1
 Unit 3 Section 16 Township 6 Range 23
 API # 30-005-61044

TOPS

Loss	~ 1000
Tubb	2523
Abn	3080
Wolfcamp	3825

← surface plug 0'-60'
 Perf & sgummed @60'

5/8" @ 1765'
 @ 100'

← shoe plug 1715'-1815'
 Perf & sgummed TAG

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

2693' ← TOC
 ← plug 3150' TAG
 3158'-3642' ← Perfs

← plug 3825'
 4 1/2" @ 4070' ← shoe plug 4070' TAG
 4322'

MCB