

30-005-61150

N-16-5s-24e

Jack J. Gryenberg

Gryenberg 16 state #2

Tops

T. Glorieta - 1355'

T. Abu - 3540'

* Set 10 sk cement Surface Plug.

* Perforate 4 1/2" casing @ 870'.

Squeeze 100' cement Plug inside + outside

4 1/2" casing. TAH

* Set 25 sk cement Plug @ 1400' - 1300'.

* Circulate brine gel to surface.

* Run + set CIBP w/35' cement @ 3485'.

10 7/8" casing
820'
circ.

7 9/8" hole

Perfs - 3585' - 3915'

4 1/2" casing

4050'

w/1425' cement