

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W Grand Ave, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103  
Revised March 25, 1999

WELL API NO.  
30-005-61161

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
LG-5574

7. Lease Name or Unit Agreement Name:

Corn Trust State

8. Well No.

1

9. Pool name or Wildcat  
Pecos Slope Abo (West)

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator

McKay Oil Corporation

3. Address of Operator

PO Box 2014, Roswell NM 88202-2014

4. Well Location

Unit Letter G : 1980 feet from the North line and 1980 feet from the East line

Section 34 Township 6S Range 23E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
4140' GL

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

Well Plugged & Abandoned as follows:

Set CIBP @ 3120'  
Set 10 sxs cement plug @ 2970-3120'  
Shot casing @ 1500'  
Pulled casing  
Set 24 sxs cement plug to cover 4 1/2" 1450-1550'  
WOC - tag plug @ 1438'  
Set 25 sxs cement plug 100' to surface  
Displaced casing w/mud between cement  
Installed dry hole marker



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tricia Moore TITLE Production Analyst DATE 1/29/2002

Type or print name Tricia Moore Telephone No. 505.623.4735

(This space for State use)

APPROVED BY [Signature] TITLE Field Rep DATE FEB 5 2002

Conditions of approval, if any: