

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-005-61185

5. Indicate Type of Lease

STATE ☐

FEE ☒

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:
OIL WELL ☒

GAS WELL ☐

OTHER

2. Name of Operator

George J. Crosby

3. Address of Operator

Unknown

4. Well Location

Unit Letter E : 1980' Feet From The North Line and 660 Feet From The West

Section 13 Township 10 Range 24 NMPM Chaves County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3542.75 GL

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

4-7-97 Move in unit + rig up to plug well.

4-8-97 Pick up tbg, run in hole + tag up c 45'.
Load hole with gel + rotate tbg with bit and
could not make hole.

Pump 35 sacks of cement, shut + woc until
4-9-97 to tag cement,

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

DATE

4-13-97

TYPE OR PRINT NAME

TELEPHONE NO.

(This space for State Use)

DATE

4-13-97

4-9-97. Pick up tbg, run in hole + tag plug
c 26 ft.

Mix 23 sacks of cement + fill hole
to surface.

Cut off csq. + rig down unit + set P + A marker.
Cut off anchors, back fill pit and
clean location.