

|                                   |                                     |                               |               |
|-----------------------------------|-------------------------------------|-------------------------------|---------------|
| COMPANY<br>Southeastern Pet. Inc. |                                     | PROPERTY NAME<br>Pogo State   | WELL NO.<br>2 |
| DATE                              | LOCATION (ULSTR)<br>UTN SEC 16-7-28 | FOOTAGE<br>660 FSL + 1980 FWL |               |
| API NO.<br>30-005-61241           | POOL<br>Elkins San Andres           |                               |               |

1. Spot a 75 SX plug @ 2260. WOC + tag
2. Perforate 4 1/2 csg. @ 380'
3. Circulate cement to surface up backside of 4 1/2 csg. leaving 4 1/2 full to surf from 380.
4. Set P+H marker, cut anchors, clean & level location.
5. Place salt-gel between plugs @ 25 lb per '66' of brine water.

#### CASING RECORD:

8 5/8 @ 320' w/200 SX 12 1/4 hole  
 4 1/2 @ 2511' w/150 SX 7 7/8 hole  
 TOC @ 1642'  
 Perts 2249  
 Top SA 1620

