

Operator McKay Oil Corp
 Well Shore #1
 Unit 3 Section 22 Township 6 Range 22
 API # 30-005-61278

TOPS

Gloria ~ 400
Upson ~ 620
Tubbs ~ 1750
Abc ~ 2422

13 3/8 @ 75'
CINC

Shoe Plug 0'-145'
(includes Surface Plug)

Plug 400'

9 5/8 @ 852'
CINC

Shoe Plug 802'-922' Tag

Est TOC 2201'

Plug 24 22' Tag

Perfs 24 72'

Plug 3143'

PBTD @ 3143'
 4 1/2 @ 2233'
 75' @ 300'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

16