Submit 3 Copies to Appropriate District Office

State of New Mexico Energy, Minerals and Natural Resources Department

Form C	-103
Revised	1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION P.O. Box 2088

Santa Fe New Mexico 875042023VED

WELL API NO. 30-005-61338		
5. Indicate Type of Lease	******	

P.O. Drawer DD, Artesia, NM 88210	5. Indicate Type of Lease STATE X FEE
DISTRICT III 000 Rio Brazos Rd., Aziec, NM 87410 FEB 1 9 1992	6. State Oil & Gas Lease No. LG 4333
SUNDRY NOTICES AND REPORTS ON WELLS ARTESIA OFFICE DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	7. Lease Name or Unit Agreement Name
Type of Well: OIL GAS WELL OTHER P&A	Skinny QO State
Name of Operator YATES PETROLEUM CORPORATION	8. Well No.
. Address of Operator	9. Pool name or Wildcat
105 South 4th St., Artesia, NM 88210	Undes. SA
· ·· == =-·····	Feet From The West Line
16 6S 25E .	Chaves County
Section 16 Township 6S Range 25E M 10. Elevation (Show whether DF, RKB, RT, GR, etc.)	NMPM Chaves County
//////////////////////////////////////	<u> </u>
1. Check Appropriate Box to Indicate Nature of Notice, Re	eport, or Other Data
NOTICE OF INTENTION TO: SUBS	SEQUENT REPORT OF:
	ALTERING CASING
ERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALIEMING CASING
EMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING	OPNS. PLUG AND ABANDONMENT X
EMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OULL OR ALTER CASING CASING TEST AND CE	OPNS. PLUG AND ABANDONMENT X
EMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING ULL OR ALTER CASING CASING TEST AND CE OTHER:	OPNS. PLUG AND ABANDONMENT X
EMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING CULL OR ALTER CASING CASING TEST AND CE OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, include work) SEE RULE 1103.	MENT JOB
EMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING ULL OR ALTER CASING CASING TEST AND CE OTHER: OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, include	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled
COMMENCE DRILLING CASING TEST AND CE THER: TO	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled
COMMENCE DRILLING CASING TEST AND CE THER: TO	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled
COMMENCE DRILLING CASING TEST AND CE OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, include work) SEE RULE 1103. 2-10-92. MIRU. ND wellhead. NU BOP. POH w/44 jts 2-7/8" 2-11-92. Set CIBP at 1350'. Circulated hole with mud. S with tubing to 147'. Circulated 10 sacks cement to surface hole back with cement. Cut off wellhead. Installed dry ho	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled
COMMENCE DRILLING CASING TEST AND CE OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, include work) SEE RULE 1103. 2-10-92. MIRU. ND wellhead. NU BOP. POH w/44 jts 2-7/8" 2-11-92. Set CIBP at 1350'. Circulated hole with mud. S with tubing to 147'. Circulated 10 sacks cement to surface hole back with cement. Cut off wellhead. Installed dry ho	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled
CASING TEST AND CE OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, include work) SEE RULE 1103. 2-10-92. MIRU. ND wellhead. NU BOP. POH w/44 jts 2-7/8" 2-11-92. Set CIBP at 1350'. Circulated hole with mud. S with tubing to 147'. Circulated 10 sacks cement to surface hole back with cement. Cut off wellhead. Installed dry ho WELL PLUGGED AND ABANDONED.	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled le marker.
COMMENCE DRILLING CASING TEST AND CE OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, include work) SEE RULE 1103. 2-10-92. MIRU. ND wellhead. NU BOP. POH w/44 jts 2-7/8" 2-11-92. Set CIBP at 1350'. Circulated hole with mud. S with tubing to 147'. Circulated 10 sacks cement to surface hole back with cement. Cut off wellhead. Installed dry ho WELL PLUGGED AND ABANDONED.	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled le marker.
EMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING CASING TEST AND CEDITHER: OTHER: OTH	MENT JOB ding estimated date of starting any proposed tubing. pot 35 sx cement at 1350'. POH . POH with tubing. Filled le marker.

CONDITIONS OF APPROVAL, IF ANY:

APPROVED BY-