

NM OIL CON. COMMISSION
Drawer DD
Artesia, NM 88210

3. RIH w/ OSTSD & Otis type XA sliding sleeve, (in open position) on 2-3/8" J-55 tbg.
4. Space out & latch onto permalach PKR at 4914'. (sliding sleeve to be set at 4362'.)
5. Otis WL set collar stop at 4330' (or 1 JT ABV sliding sleeve).
6. SWAB and flow back to CLN up well (ABO ZONE).
7. Retrieve collar stop, close sliding sleeve and retrieve blanking plug.
8. Flow back well to CLN up BTM perfs (Cisco zone). If Swabbing is necessary, set collar stop above sliding sleeve.
9. Retrieve collar stop, shut-in well until sales line has been tied-in.