

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.O.S.	<input checked="" type="checkbox"/>
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

RECEIVED

Form C-103
Revised 10-1-78

MAR 24 1983

O. C. D.
ARTESIA, OFFICE

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.
LG 335

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- P&A	7. Unit Agreement Name
2. Name of Operator Yates Petroleum Corporation ✓	8. Farm or Lease Name Springer TK State
3. Address of Operator 207 South 4th St., Artesia, NM 88210	9. Well No. 2
4. Location of Well UNIT LETTER 0 660 FEET FROM THE South LINE AND 1980 FEET FROM THE East LINE, SECTION 23 TOWNSHIP 4S RANGE 24E NMPM.	10. Field and Pool, or Whidcut Und. Pecos Slope Abo
11. Elevation (Show whether DF, RT, GR, etc.) 4043.6' GR	12. County Chaves

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPHS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows:

1. Pull rods, pump and tubing.
2. Set CIBP at 3600'.
3. Cut and pull 4½" casing from approximately 3175'. Cement bond log show top of cement at 3250'.
4. GIL w/tubing and spot cement on CIBP up to 50' above 4½" casing stub. Tag this plug.
5. Spot cement plug from 1645'-1545' across top of Glorieta (1595').
6. Spot cement plug from 1014'-914' across 10-3/4" casing shoe. Tag this plug.
7. Place 10-15 sack cement plug at surface and install regulation abandonment marker.

Verbal approval for the plugging procedure above given by Mr. Larry Brooks, NMOCD, Artesia on 3-23-83.

NMOCD, Artesia to be notified in time to witness plugging operations.

13. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Larry Brooks TITLE Production Supervisor DATE 3-24-83

APPROVED BY M. Williams TITLE OIL AND GAS INSPECTOR DATE MAR 31 1983

CONDITIONS OF APPROVAL, IF ANY:

OIL AND GAS INSPECTOR