

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

**OIL CONSERVATION DIVISION**  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-005-63052
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2982
7. Lease Name or Unit Agreement Name Quincy AMQ State
8. Well No. 9
9. Pool name or Wildcat Acme San Andres, Southeast
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3938' GR

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Convert to SWD
2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South 4th St., Artesia, NM 88210
4. Well Location Unit Letter <u>G</u> : <u>2310</u> Feet From The <u>North</u> Line and <u>2310</u> Feet From The <u>East</u> Line Section <u>12</u> Township <u>8S</u> Range <u>27E</u> NMPM <u>Chaves</u> County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3938' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
<b>NOTICE OF INTENTION TO:</b>	<b>SUBSEQUENT REPORT OF:</b>
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: Convert to SWD <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to convert well to a SWD well as follows:

1. Load well. POOH with rods and pump. Nipple down tree and nipple up and test BOP. POOH with production tubing.
2. TIH with nickel plated injection packer and 2-7/8" plastic coated tubing. Set packer at 2100'±.
3. Pressure test annulus.
4. Begin disposal as soon as OCD approval is received.

NOTE: NOTIFY OCD-ARTESIA (748-1283) 24 HOURS PRIOR TO COMMENCING OPERATIONS AND IN SUFFICIENT TIME TO WITNESS MECHANICAL INTEGRITY TEST.

RECEIVED

OIL CON. DIV.  
DIST. 2

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE July 10, 1995  
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

APPROVED BY [Signature] TITLE SUPERVISOR, DISTRICT II DATE JUL 12 1995

CONDITIONS OF APPROVAL, IF ANY:

[Signature] Field Rep #