Submit 3 Copie	1
to Appropriate	

State of New Mexico Energy, Minerals and Natural Resources Department

4	
151	F
O NO	R
V	

orm C-103 levised 1-1-89

DISTRICT I P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION

P.O. Box 2088

WEI	L API NO.
	30-005-63107
5.	Indicate Type of Lease STATE FEE X
6.	State Oil & Gas Lease No.
7.	Lease Name or Unit Agreement Name
-	McClintock
8.	Well No.
	1

DISTRICT II Santa Fe, New Mexico 87504-2088	
P.O. Drawer DD, Artesia, NM 88210	5. Indicate Type of Lease STATE FEE X
DISTRICT III 1000 Rio Brazos Rd., Azzec, NM 87410	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	
A DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN ON PLUG BACK TO A	7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE TAPPLICATION FOR PERMIT	,
(FORM C-101) FOR SUCH PROPOSALS.)	- McClintock
1. Type of Well: OIL GAS	
WELL OTHER	8. Well No.
2. Name of Operator	1
Primero Operating, Inc.	9. Pool name or Wildcat
3. Address of Operator	Wildcat, SanAndres
P.O. Box 1433, Roswell, NM 88202-1433	Arrided 5 data mare 5
4. Well Location Unit Letter E : 2139	508 Feet From The West Line
Unit Letter : Feet Fixen the	
Section 30 Township 9S Range 28E	NMPM Chaves County
Section Section (Show whether DF, RKB, RT, GR, etc.)	
	<i>\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\</i>
11. Check Appropriate Box to Indicate Nature of Notice, R	Report, or Other Data
	SEQUENT REPORT OF
NOTICE OF INTENTION TO:	502402111121311
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
	IG OPNS. PLUG AND ABANDONMENT
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLIN	G OPNS FEOGRADO ADARDONNELLI
PULL OR ALTER CASING CASING TEST AND C	EMENT JOB
OTHER: OTHER:	
OTHER: OTHER: OTHER: OTHER: 12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl. work) SEE RULE 1103.	luding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl. work) SEE RULE 1103.	luding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl. work) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN	luding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17	luding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17- 6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce	92' tubing SDFN 107 1997 3
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17- 6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs:	92' tubing SDFN 107 1997
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/ 6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640'	92' tubing SDFN 107 1997
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17-6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320'	92' tubing SDFN 107 1997 3
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	luding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 107 1897 1897 1897 1897 1897 1897 1897 189
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17 6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 10. PCD SCENED NO. ARTESIA
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 10. PCD SCENED 10. ARTESIA wipment off location.
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 10. SDFN 10. SDFN 10. ARTESIA 10. ST TO-2 10. ST TO-2 10. ST TO-2
12. Describe Proposed or Completed Operations (Clearly state all perinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 10. PCD SCENED 10. ARTESIA wipment off location.
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 10. 100 SDFN 10
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface	92' tubing SDFN 10. OCD ECEIVED 10. ARTESIA POST IN-2
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incliwork) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbis mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag @ 1640' Plug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface RDMO pulling unit. Install dry hole marker. We will clean and level location at a later date when Marbob moves eq	92' tubing SDFN 107 1997 1997 1997 1997 1997 1997 1997
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17/6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Piug 1 120 sx@ 1850' tag @ 1640' Piug 2 35 sx @ 450' tag @ 320' Plug 3 10 sx @ 30' to surface RDMO pulling unit. Install dry hole marker. We will clean and level location at a later date when Marbob moves eq	g2' tubing SDFN 10. OCD ECEIVED 10. ARTESIA puipment off location. Post TD-2 Post TD-2 Post DATE 08/1997/14
12. Describe Proposed or Completed Operations (Clearly state all perinent details, and give perinent dates, inclework) SEE RULE 1103. 6/4/97: MIRU Pulling unit, POH w/tubbing and ND Wellhead. SDFN 6/5/97: MIRU Wireline unit, Cut 4½" casing @1800' and POH. RIH w/17-6/6/97: RIH to 2450', load hole w/mud, spot 5 bbls mud laden w/floce POH LD pipe and pump the following plugs: Plug 1 120 sx@ 1850' tag@ 1640' Plug 2 35 sx@ 450' tag@ 320' Plug 3 10 sx@ 30' to surface RDMO pulling unit. Install dry hole marker. We will clean and level location at a later date when Marbob moves equal the complete to the best of my knowledge and belief.	92' tubing SDFN 10. OCD ECEIVED ARTESIA 10. 10. 10. 10. 10. 10. 10. 10

TITLE Soil Rep