

0155

Form 3160-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
YATES PETROLEUM CORPORATION (505) 748-1471

3. Address and Telephone No.
105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
660' FSL & 1980' FWL of Section 30-T2S-R21E (Unit N, SESW)

5. Lease Designation and Serial No.
NMNM-36379

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
Grace Federal #1

9. API Well No.
30-011-20036

10. Field and Pool, or Exploratory Area
Wildcat Abo

11. County or Parish, State
DeBaca Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION
<input checked="" type="checkbox"/> Notice of Intent	<input checked="" type="checkbox"/> Abandonment
<input type="checkbox"/> Subsequent Report	<input type="checkbox"/> Recompletion
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Plugging Back
	<input type="checkbox"/> Casing Repair
	<input type="checkbox"/> Altering Casing
	<input type="checkbox"/> Other
	<input type="checkbox"/> Change of Plans
	<input type="checkbox"/> New Construction
	<input type="checkbox"/> Non-Routine Fracturing
	<input type="checkbox"/> Water Shut-Off
	<input type="checkbox"/> Conversion to Injection
	<input type="checkbox"/> Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to plug and abandon well as follows:

1. Nipple up and test BOP.
2. Fill hole with 10 ppg salt gel containing 25#/bbl water.
3. Determine free point of 5-1/2" casing. Cut and pull as much casing as possible. Top of cement is at 2000'±.
4. Spot a 50 sack cement plug (150' in open hole) across 5-1/2" casing stub. WOC. Tag plug.
5. Spot a 40 sack cement plug from 1075-925' across surface casing stub (at 1000').
6. Spot a 25 sack cement plug from 100' to surface.
7. Install regulation abandonment marker.

NOTIFY BLM-ROSWELL (505-624-1790) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS

RECEIVED
OCT 18 1995
OIL CON. DIV.
DIST. 2

14. I hereby certify that the foregoing is true and correct

Signed Rusty Klein Title Production Clerk Date Sept. 14, 1995

(This space for Federal or State office use)

Approved by _____ Title _____ Date _____

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side