

Y.P.C. Ramon ABA ST. #1

SUR. @ 1080

Set CIBP @ 2850 w/ 35' cmt.
Cut off $4\frac{1}{2}$ @ 2150 & pull.
Set stub plug from 2100-2200
& tag.

^{50' below}
pull to $8\frac{5}{8}$ " shoe @ 1080

pump 100' plug from 1030-1130
& tag.

Run CBL
perf. @ 130-48 & swap

~~IF~~ If non-prod. spot

plug 50' in/out of perms

spot 15 SxS @ sur & install
DHM.