

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1 ✓
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

**RECEIVED**  
NEW MEXICO OIL CONSERVATION COMMISSION

**APR 29 1974**

**O. C. C.**  
**ARTESIA, OFFICE**

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No. OG 6058	
7. Unit Agreement Name NA	
8. Farm or Lease Name Clements-Buffalo Valley Com	
9. Well No. 1	
10. Field and Pool, or Wildcat Buffalo Valley Penn.	
12. County Chaves	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-
2. Name of Operator Clinton Oil Company
3. Address of Operator Post Office Box 94129, Houston, Texas 77018
4. Location of Well UNIT LETTER <u>D</u> <u>990</u> FEET FROM THE <u>North</u> LINE AND <u>990</u> FEET FROM THE <u>West</u> LINE, SECTION <u>1</u> TOWNSHIP <u>155</u> RANGE <u>27E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) DF 3532'

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 5-2-74 1) Set cement plug in open hole 8250'-8354'.  
2) Run 3 7/8" bit, dress cement plug to 8270'.  
3) Set whipstock at 8270'.  
4) Run 3 7/8" bit, drill new hole to a true vertical depth of 8370'.

Note: Sent copy to all offset operators.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>W. A. Gressett</u>	TITLE <u>District Manager</u>	DATE <u>April 24, 1974</u>
APPROVED BY <u>W. A. Gressett</u>	TITLE <u>OIL AND GAS INSPECTOR</u>	DATE <u>APR 30 1974</u>
CONDITIONS OF APPROVAL, IF ANY:		