All Hugs Dudger

Mans . TOPS Operator Smith Inc. Well Twnship 1 Range 28 Unit Section 19 Per 2532 all but ist plug 30-0 15 - 01457 API# MATES ~ Sco 2 nivers 600 -Plus 60'- 0' Surfac Scurrs へ 850 へ 050 Queen r 1500 Gray byn ィ 850 دمم Contact OCD 24 hrs. prior to any work done. Salt gel mud consisting of 10# brine with 25# of gei per barrel must be placed between each plug. install dry hole marker as per Rule 202.B.2 Plug 500' TAC. Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated. Shoe and stub plugs will be 50' above and below shoe or stub and tagged. Surface plug will be from 0' - 60' Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists. Plugs to be tagged will be indicated. Plug 1850' TAG.