

9/23/87

Kersey + Co Tr 1 #2 Red Lake Q6 SA
C-29-17-28

- 1 Set Pkr @ 1200' + pump 125 SX Cement + Tag
- 2 Pump 10 SX down 7" x 8" annulus
- 3 If we cannot pump down 7" x 8" annulus
perf @ 350' + squeez w/ 50 SX 25 out +
leave 25 SX in + Tag
- 4 Spot 25 SX cmt @ 350 inside 7"
- 5 10 SX @ surface