

7. ND BOP. Clean out csg hd. Monitor all csg strings as necessary to ensure pressure has been eliminated @ surf <sup>PRIOR TO CUTTING OFF WELL HEADS.</sup>
8. Cut off csg 3 feet below ground level & remove wellhead. Weld on steel plate. Install P & A marker. Reclaim location. <sup>WCH</sup>

WCH

KDK 5/8/08  
K. D. Krawietz

GDK  
G. D. Kimbrough

DRM 5/8/08  
D. R. McKelvey

BNB (for 5/8/08)  
B. N. Brown

eauplug.txt