## 5. Mud Program

(a) The mud program has been designed to minimize the volume of H2S circulated to surface. Proper mud weight and safe drilling practices (for example, keeping the hole filled during trips) will minimize hazards when drilling in H2S bearing formations.

## 6. Metallur, y

(a) All drill strings, casings, tubing, wellhead, blowout preventers, drilling spools, kill lines, choke manifold and lines, and valves shall be suitable for H2S service.

## 7. Commun cation

(a) I wo way radio and cellular telephone communication will be available in company vehicles.

## C. Diagram of Drilling Location

1. Attached s a diagram representing a typical location layout as well as the location of H2S monitors, briefing areas, and wind direction indicators.