

Operator C.F.M. W Co
Well Williams - 3
Unit B Section 25 Township 18 Range 26
API # 30-015--00318

TOPS

Yates _____
T. Salt _____
B. Salt _____
Glorieta _____
Bone Sp. _____
Abo _____
Wolfcamp _____
Morrow _____
Devonian _____
Fusselman _____
Other S.A. 1130
Queen 300

← 60' Surface Plug

← 300'

7" ← 950' Tag
950' Cak-Cure
OH 1080

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug
- Install dry hole marker as per rule 202.B.2
- Plugs are to be set from point indicated up. Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required cement must be placed inside and outside of all casing string(s), in the correct footage or sacks required, if no cement exists.
- Plugs to be tagged will be indicated.