

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
--

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Water Injection Well</b>	7. Unit Agreement Name --
2. Name of Operator <b>American Petrofina Company of Texas</b>	8. Farm or Lease Name <b>Resler Yates State</b>
3. Address of Operator <b>Box 1311, Big Spring, Texas 79720</b>	9. Well No. <b>304</b>
4. Location of Well UNIT LETTER <b>G</b> <b>1800</b> FEET FROM THE <b>North</b> LINE AND <b>1800</b> FEET FROM THE <b>East</b> LINE, SECTION <b>28</b> TOWNSHIP <b>18S</b> RANGE <b>28E</b> NMPM.	10. Field and Pool, or Wildcat <b>Artesia</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3539 Gr.</b>	12. County <b>Eddy</b>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER <input type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

**Start work approximately 10-30-68**

- Run 2" EUE tubing to bottom and spot 25 sack cement plug over casing perforations 2048-74 using 10# mud as displacement medium.
- Cut off 4 1/2" casing at 650' and pull.
- Spot 25 sack cement plug at 4 1/2" casing stub and bottom of 7" casing.
- Place 5 sack cement plug in top of 7" casing.
- Place 4" pipe marker.

RECEIVED  
OCT 15 1968  
ARTESIA DISTRICT

JCC/js

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. M. Denson J. M. Denson TITLE Asst. Dist. Mgr. of Production DATE 10-14-68

APPROVED BY W. A. Gressett TITLE Oil and Gas Inspector DATE 10-14-1968

CONDITIONS OF APPROVAL, IF ANY: