

30. Apr. 22250 4-5-19-26

Newbury Prod. Co.

Morrison Com. #1

* Set 10 sk surface Plug.

* Perforate 8 5/8" casing @ 360'.

Squeeze 100' cement Plug inside + outside 8 5/8" csj. TAG

* Set 25 sk cement Plug 1364'-1264'. TAG

* Circulate brine gel.

* Run + set CIBP @ 2400'.

w/35' cement.

111
X

= Perf. 2451'-2778'.

111
X

CIBP w/35' cement
set @ 6700'.