

14. Install dry hole marker. Weld on marker:

NM DP ST #5
660 FNL & 660 FEL
Sec. 28 T20S R28E
Date Plugged

15. RDMO

16. Clean location.

#) A list of materials left on location, as well as transfers for material removed from the location should be forwarded to Materials Management in Midland.

RWG
RWG
1/25/88

BRB
BRB
1/25

M. C. W. Jellison
Division Operations Superintendent