NERGY AND MINERALS DEPARTMENT	
OIL CONSERVATION DISTRIBUTION DISTRIBUTION SANTA FE SANTA FE, NEW MEXICIAN 75 011484	Form C-103 Revised 10-
U.S.G.S. LAND OFFICE OFERATOR ARTESIA, OFFICE	Sa. Indicate Type of Lesse State Fee S. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS 100 HOT USE THIS FORM FOR PROPOSALS TO DRILL ON TO DECEEN OR FLUG BACK TO A DIFFERENT RESERVOIN. USE "APPLICATION FOR PERMIT -" FORM C-101) FOR SUCH PROPOSALS.)	7. Unit Agreement Name
OIL XX CAB OTHER-	8. Farm or Lease Name
DINERO OPERATING COMPANY	WILLIAMS
Address of Operator	9. Well No.
P. O. DRAWER 10505, MIDLAND, TEXAS 79702	1 10. Floid and Pool, or Wildcat B
UNIT LETTERNN 1980 FEET FROM THE West LINE AND 660 FEET	Spring-S. Culebra Bl
THE South LINE, SECTION 25 TOWNSHIP 23-S HANGE 28-E	***• <u> </u>
15. Elevation (Show whether DF, RT, GR, etc.)	G.L. EDDY
6. Check Appropriate Box To Indicate Nature of Notice, Report of	
	JENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING PLUG AND ABANDONMEN
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK COMMENCE DRILLING OPHS.	ALTERING CASING Plug and Abandonmen
COMMENCE DRILLING OPNS.	PLUG AND ABANDONMEN
COMMENCE DRILLING OPNS. COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JOB OTHER OTHER 7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1103.	PLUG AND ABANDONMEN
COMMENCE DRILLING OPHS. COMMENCE DRILLING OPHS. CASING TEST AND CEMENT JOB OTHER OTHER 7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1 fos. 1. Pull out of hole with the tubing.	PLUG AND ABANDONMEN
COMMENCE DRILLING OPNS. COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JQB OTHER 7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, incl work) SEE RULE 1903. 1. Pull out of hole with the tubing. 2. Set C.I.B.P. at 6,400'.	PLUG AND ABANDONMEN uding estimated date of starting any pro
 COMMENCE DRILLING OPNS. COMMENCE DRILLING OPNS. CASING TEST AND CEMENT JOB OTHER	PLUG AND ABANDONMEN uding estimated date of starting any pro
 COMMENCE DRILLING OPNS. COMMENCE DRILLING OPNS. CASING TEST AND CEMENT Jab OTHER OTHER OTHER The proposed of Completed Operations (Clearly state all pertinent details, and give pertinent dates, inclearly state all pertinent details, and give pertinent dates, inclearly state all pertinent details. Pull out of hole with the tubing. Set C.I.B.P. at 6,400'. Ran in hole with tubing. Set 25 sack plug from 6,400' to 6,050' Set 25 sack plug from 2,650' to 2,300'. This covered the top of and the 8 5/8" casing shoe at 2,503'. 	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600'
 commence DailLine OPN3. commence DailLine OPN3. commence DailLine OPN3. casine TEST AND CEMENT JGB other other other other other commence DailLine OPN3. casine TEST AND CEMENT JGB other oth	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 Commence Data in the solution of the	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 commence DailLine OPN3. commence DailLine OPN3. commence DailLine OPN3. casine TEST AND CEMENT JGB other other other other other commence DailLine OPN3. casine TEST AND CEMENT JGB other oth	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 COMMERCE DAILLING ON COMMENCE DAILLING OPNS. COMMERCE DAILLING OPNS. CASING TEST AND COMMENT JOS Set C.I.B.P. at 6,400'. Set C.I.B.P. at 6,400'. Set 25 sack plug from 2,650' to 2,300'. This covered the top of and the 8 5/8" casing shoe at 2,503'. Set a 25 sack plug from 1,350' to 1,000'. WOC for 4 hours. Tag Set 25 sack plug from 600' to 250'. This covered the 13 3/8" ca Set marker in 10 sacks of cement. * This covered the top of the Bone Spring at 6,350'. 	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 COMMETER DATE OF PROPOSED OF COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, inclearly state all pertinent details, and give pertinent dates, inclearly state all pertinent details. and give pertinent dates, inclearly state all pertinent details. And give pertinent dates, inclearly state all pertinent details. And give pertinent dates, inclearly state all pertinent details. And give pertinent dates, inclearly state all pertinent details. And give pertinent dates. 7. Describe Proposed or Completed Operations (Clearly state all pertinent details. and give pertinent dates, inclearly state all pertinent details. And give pertinent dates, inclearly state all pertinent details. 1. Pull out of hole with the tubing. 2. Set C.I.B.P. at 6,400'. 3. Ran in hole with tubing. Set 25 sack plug from 6,400' to 6,050' 4. Set 25 sack plug from 2,650' to 2,300'. This covered the top of and the 8 5/8" casing shoe at 2,503'. 5. Set a 25 sack plug from 1,350' to 1,000'. WOC for 4 hours. Tage 6. Set 25 sack plug from 600' to 250'. This covered the 13 3/8" ca 7. set marker in 10 sacks of cement. 	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 COMMERCE DAILLING ON COMMENCE DAILLING OPNS. COMMERCE DAILLING OPNS. CASING TEST AND COMMENT JOS Set C.I.B.P. at 6,400'. Set C.I.B.P. at 6,400'. Set 25 sack plug from 2,650' to 2,300'. This covered the top of and the 8 5/8" casing shoe at 2,503'. Set a 25 sack plug from 1,350' to 1,000'. WOC for 4 hours. Tag Set 25 sack plug from 600' to 250'. This covered the 13 3/8" ca Set marker in 10 sacks of cement. * This covered the top of the Bone Spring at 6,350'. 	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 CHANCE PLANE CHANCE PLANE CHANCE PLANE COMMETER CASING CHANCE PLANE COMMETER CASING COMMETER CASING CHANCE PLANE CHANCE PLANE COMMETER CASING CHANCE PLANE COMMETER CASING COMMETER CASING CHANCE PLANE CHANCE PLANE COMMETER CASING COMMETER CASING CHANCE PLANE CHANCE PLANE<td>PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.</td>	PLUG AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'.
 COMMERCE DENUE COMMERCE DENUE OF DESCRIPTIONS COMMERCE DENUELING OF MS. COMMERCE DENUE COMPLETED OPERATIONS (Clearly state all pertiment details, and give pertiment dates, inclusors) SEE RULE 1703. Pull out of hole with the tubing. Set C.I.B.P. at 6,400'. Ran in hole with tubing. Set 25 sack plug from 6,400' to 6,050' Set 25 sack plug from 2,650' to 2,300'. This covered the top of and the 8 5/8" casing shoe at 2,503'. Set a 25 sack plug from 1,350' to 1,000'. WOC for 4 hours. Tag Set 25 sack plug from 600' to 250'. This covered the 13 3/8" ca set marker in 10 sacks of cement. * This covered the top of the Bone Spring at 6,350'. Worked completed Jan. 24, 1984. 	PLUE AND ADANDONMEN uding estimated date of starting any pro . * ' the Delware at 2,600' g top of cement at 990'. asing shoe at 422'. Post 2 Y