

Vernon E. Faulconer, Inc

WORKOVER REPORT

Well Name: **FOREHAND FEDERAL #1**

Field: **CARLSBAD, S.**

Date:

Co. Consultant: **DON REIDLE**

- 12-11-00** MI RU Key Well Service. Ld LSW, HU to csg. Ld'd w/330 bbls press to 1500#. Held 10 mins, press @ 1300# tbg & csg. Bled off csg & tbg. Csg went dead, tbg still flw'g @ 200#. Flw 5 mins, went to 0#. Call for tbg, eng csg vlv to 3000#. Ball vlv's chng, (1) vlv wk on 2nd vlv. Csg blw & started to unld. Pmp fl dwn csg. 30 bbls to kill csg, press went to 500#. HU tbg & csg to tk. Leave open to tk on pinched vlv. SDFN.
CTD: \$ 3,071.00
TCTD:\$ 3,071.00
- 12-12-00** Travel to lse. Well is dead, very small blw on tbg. Chg 2nd vlv on csg & tightened bolts. Rem bolts frm well flange. PU on tbg, rem wrap around. Flange has Vam thread box. Call tool company. Get chg over Vam thread to 8 rmd thread. Rem WH. Install BOP & floor. Wk tbg to free pkr, wk to 78000#. Wk 3½ hrs, unld 1000', 2-3/8" N-80 EUE, 8 rmd tbg, run stretch, free pts show to stuck @ 9780'. Call office. Pull to 93000#. Wk pipe, stretch, free pts shows to be stuck @ 9780'. Leave 90000# pulled on tbg. Close BOP. Secure well. SDFN.
CTD: \$ 1,967.09
TCTD:\$ 5,038.09
- 12-13-00** Travel to loc. Meet Rotary Wireline Service. RU to run free pt & bk off tbg. RIH w/free pt tool 1-7/16" OD. Set dwn @ 10607' KB meas. Pipe free @ 10605'. Call office. POOH w/free pt tool. WO orders. RU & RIH w/1.8125" impression blk. Looks like sand impression on side of blk. Bk off tbg @ 10588' line meas KB & POOH. RU MYT elevators & POOH w/tbg. POOH w/270 jts VAM tbg. Close BOP. Secure well. SDFN.
CTD: \$ 6,568.60
TCTD:\$ 11,606.69
- 12-14-00** Travel to lse. Start rig. POOH w/VAM tbg, 168 stds, 336 jts. VAM pin looking up on fish. Fishing tools on loc. Unld pit & pmp, 6 DC's, 17 jts, 3-3/4" wash pipe (496'). Need 4 more jts of wash pipe. Need to get frm Odessa, TX. Rem VAM collars & cut off pin to take to machine shop in Hobbs, NM to have x-overs made. Fnd 2 jts w/holes in pipe. PU DC's frm grnd. Std in derrick in dbls. RIH w/wash pipe, 17 jts, top sub, 1 jt & 8 rmd tbg. Close BOP. Secure well. Haul wtr to fill pit & wtr tk + G&L RU tools.
CTD: \$ 2,765.97
TCTD:\$ 14,372.66
- 12-15-00** Travel to loc. Start rig. Tally wash pipe. RIH w/3-3/4" wash pipe shoe, 3-3/4" wash pipe, 649' bumper sub, oil jars, 6 DC's & 185' VAM tbg. Install SN & stdg vlv. Test tbg IH, tally tbg IH. Tag 4½" liner @ 8487'. Get into liner to 8502'