

C/S 77

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil well gas well other

2. NAME OF OPERATOR
Perry R. Bass ✓

3. ADDRESS OF OPERATOR
P. O. Box 2760 Midland, Texas 79702

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 660' FSL & 1980' FEL Unit Letter 0
AT TOP PROD. INTERVAL:
AT TOTAL DEPTH: Same As Above

5. LEASE
LC 068431

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME
Poker Lake Unit RECEIVED

8. FARM OR LEASE NAME
Poker Lake Unit

9. WELL NO. JAN 18 1983
54

10. FIELD OR WILDCAT NAME O. C. D.
Wildcat ARTESIA, OFFICE

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA
Sec. 4, T24S, R30E

12. COUNTY OR PARISH Eddy 13. STATE New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)
3434.6' GL

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>		<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>		<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>		<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>		<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>		<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>		<input type="checkbox"/>
CHANGE ZONES	<input type="checkbox"/>		<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>		<input type="checkbox"/>
(other)			

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Drilled 6-1/4" hole to 6150' 12-16-82. Logging Delaware. Preparing to plug & abandon. Mark Gosch (Bass) talked with Mr. George Stewart with MMS on 12-16-82 & 12-17-82 on plugging procedures. Plan to plug as follows:
 Set plug #1 @ 3900'-3800' with 250 sx Class "C" with additives
 Set plug #2 @ 1370'-1020' with 75 sx Class "C" with additives
 Set 10 sx @ surface, with marker 12-17-82

RECEIVED
DEC 22 1982

Subsurface Safety Valve: Manu. and Type _____ N/A _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED David R. Glass TITLE Sr. Prod. Clerk DATE 12-21-82

(This space for Federal or State office use)

APPROVED BY (ORIG. SGD.) DAVID R. GLASS DATE _____

CONDITIONS OF APPROVAL IN ANY _____

JAN 14 1983

JAMES A. GILLHAM
DISTRICT SUPERVISOR *See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.