

RECEIVED

Form 3160-5
(June 1990)

MAY 6 10 45 AM '93

NM OIL CONS. COMITE
Drawer DD
Artesia. NM 88210UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Bettis Brothers, Inc. ✓

3. Address and Telephone No.

500 West Texas, Suite 820, Midland, Texas 79701 (915) 685-4128

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

2310' FNL & 660' FEL of Sec. 5, T-25-S, R-29-E

FORM APPROVED

Budget Bureau No. 1004-0135

Expires: March 31, 1993

5. Lease Designation and Serial No.

NM 15302

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Gulf "5" Federal No. 1

9. API Well No.

30-015-25312

10. Field and Pool, or Exploratory Area

Rustler Bluff Atoka

11. County or Parish, State

Eddy, New Mexico

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent☐ Subsequent Report☐ Final Abandonment Notice

TYPE OF ACTION

☐ Abandonment☐ Recompletion☐ Plugging Back☐ Casing Repair☐ Altering Casing☐ Other☒ XXX

Change of Plans

☐ New Construction☐ Non-Routine Fracturing☐ Water Shut-Off☐ Conversion to Injection☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Bettis Brothers, Inc. previously sought and received permission to plug and abandon the above captioned well (approval date January 13, 1993).

At this time Bettis Brother, Inc. is contemplating a recompletion of this well if an offset well recompletion is successful. Recompletion information is as follows:

- 1.) Set a CIBP at 12,300' K.B., dump 35 feet of cement on top; pressure check plug with 1500 psig.
- 2.) Set a CIBP at 10,180' K.B., dump 35 feet of cement on top; pressure check plug with 1500 psig.
- 4.) Acidize with 3000 gallons, swab/flow to clean-up and test.
- 5.) Fracture treat, swab/flow to clean-up and test.
- 6.) Install surface equipment.
- 7.) Run potential test.

If this well is not recompleted in the above mentioned zone another plug and abandon procedure will be sent in for approval.

14. I hereby certify that the foregoing is true and correct

Signed

Sheryl L. Jones

Title Agent for Bettis Brothers, Inc.

Date 5/5/93

(This space for Federal or State use)

ORIG. SGT. DAVID R. GILS

PETROLEUM ENGINEER

Approved by

Conditions of approval, if any:

Title

Date

JUN 14 1993