UNITED STATES EN POERING OFFRIGE PROPERTY ALICE DIVISION DISTRICT BUREAU OF LAND MANAGEME

OM B No. 1004-0137

		TANK TO THE TANK THE THE
SUNDRY NOTICES	AND	REPORTS ON WELLS

NMLC032326B 6. If Indian, Allottee or Tribe Name

Do not use this form for proposals to drill or to re-enter a abandoned well. Use Form 3160 - 3 (APD) for such proposals.

SUBMIT IN TRIPLICATE- Other instructions on reverse side.

Fee

NMNM70975A

7. If Unit or CA/Agreement, Name and/or No.

1 Type of Well"					NIMINIM	1/U9/3A		
1. Type of Well Oil Well	Gas Well	Other	SW INJECTION	NC	8. Well Name			
gapill - T				and the second s	LM Woo	olworth #703		
2. Name of Operator BET	WELL OIL & (3AS			9. API Well			
			3b. Phone No. (include o	rea code)	30-02	<u>5-11253 </u>		
PO Box 22577 L	3b. Phone No. (include area code) 3ox 2257/7, Hialeah, Florida 33012 305-821-8300				10. Field and Pool, or Exploratory Area			
A Landing of Well Contents Con T. R. M. or Survey Description)					LM Woolworth			
NAVSE 27 25S 37E NMP				11. County or Parish, State				
61.81 J 198	30 FSL 198	0 FEL			LEA ·	- NM		
12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA								
TYPE OF SUBMISSION		TYPE OF ACTION						
	Acidize	T T	Deepen	Production (Str	nt/Resume)	Water Shut-Off		
Notice of Intent	Alter Casin	. Ē	Fracture Treat	Reclamation	[Well Integrity		
	Casing Re		New Construction	Recomplete	[Other		
Subsequent Report Casing Repair New Construction Recomplete Change Plans Plug and Abandon Temporarily Al				mendon				
Final Abandonment No			Plug Back	Water Disposal				
Convert to injection Last ring that								
13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof.								

if the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has

Final plugging report from plugger & lease operator

Approved as to plugging of the well Born. Liability under bond is retained until merisce restoration is completed.

		and the second s					
14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)	1						
Robert C. Bredemeyer	Title	Foreman					
Signature & Buelle	Date	9-30-04	a la fa di Mada a mana di Mada a mana				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE							
Approved by CORIG SCOLONIANIO & GLASS		Title	Date	OCT 15 2004			
Approved by (CRIC SGD) DAMID & GLASS Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon.		Office					
Title 18 U.S.C. Section 1001 and Taile 43 U.S.C. Section 1212, make it a crime for any States any false, fictitious or fraudulent statements or representations as to any matter	person r within	knowingly and willfully to make to its jurisdiction.	any depart	ment or agency of the United			

(Instructions on page 2)

GWW

determined that the site is ready for final inspection.)

MAYO MARRS CASING PULLING INC. BOX 863 KERMIT, TEXAS 79745

BETWELL OIL & GAS

Lease: LANGLIE MATTIX WOOLWORTH UNIT # 703

Project: P & A – CEMENTING REPORT

07-13-04 - SPOT 25 SXS @ 3107'-2929' & TAG

07-13-04 - PERFORATE @ 2470'

07-13-04 - SQUEEZE 25 SXS @ 2470'-2224' & TAG

07-14-04 - PERFORATE @ 990' -

07-14-04 - SQUEEZE 25 SXS @ 990'-900' & TAG

07-14-04 - PERFORATE @ 411'

07-14-04 - SQUEEZE 35 SXS @ 411'-360' & TAG

07-14-04 - PERFORATE @ 350'

07-14-04 - SQUEEZE 25 SXS @ 350'-262' & TAG

07-15-04 - SPOT 10 SXS @ 100' TO SURFACE

INSTALL DRY HOLE MARKER CIRCULATE 10# MUD