Submit 3 Copies To Appropriate District	State of	New Me	exico		Form C-103	1
Office District I	Energy, Minerals	and Natu	ral Resources		Revised March 25, 1999	<u>, </u>
1625 N. French Dr., Hobbs, NM 88240				WELL API NO. 30-025-03866		╛
District II 1301 W. Grand Ave., Artesia, NM 88210 District III 1220 South St. Francis Dr.			5. Indicate Type of Lease STATE FEE			
1000 Dio Prezos Dd. Aztec NM 97410			6. State Oil & Gas Lease No.			
District IV Santa Fe, NM 8/303			Federal-	LC-062383		
1220 S. St. Francis Dr., Santa Fe, NM 87505			·			
SUNDRY NOTICES AND REPORTS ON WELLS				7. Lease Nan	ne or Unit Agreement Name:	7
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH						
PROPOSALS.)	CATION FOR FERMIT (FOR	M C-101) F	JK SUCH			ı
1. Type of Well:				Wast I seein -	4 II:4	
Oil Well Gas Well Other Water Injection Well				West Lovington Unit		
2. Name of Operator				8. Well No.		
Pure Resource				12		
3. Address of Operator 500 West Illinois – Midland,	Tayor 70701			9. Pool name or Wildcat		
300 West Initiols – Widiand,	1 exas / 9/UI			Lovington Upper San Andres, West Oil (40990)		
4. Well Location				(40220)		\dashv
						1
Unit Letter E: 19	980feet from the	_NORTH	I line and	_660feet	from theWESTline	İ
Section 4		17S	Range 36E	NMPM	Lea County	
	10. Elevation (Show w	vhether D	R, RKB, RT, GR, etc)		7
· · · · · · · · · · · · · · · · · · ·	<u> </u>				and the state of t	
II. Check	Appropriate Box to I	ndicate				
		_	NOTICE OF INTENTION TO: SUB			
PERFORM REMEDIAL WORK	PLUG AND ABANDON		REMEDIAL WORK	· [☐ ALTERING CASING	
TEMPORARILY ABANDON	PLUG AND ABANDON CHANGE PLANS		COMMENCE DRIE		一] PLUGAND [24.	
TEMPORARILY ABANDON	CHANGE PLANS		COMMENCE DRI	LLING OPNS.[PLUG AND (25). ABANDONMENT	
TEMPORARILY ABANDON		_		LLING OPNS.[PLUG AND (25). ABANDONMENT	
TEMPORARILY ABANDON PULL OR ALTER CASING	CHANGE PLANS		COMMENCE DRII CASING TEST AN CEMENT JOB	LLING OPNS.[PLUG AND (25). ABANDONMENT	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	CHANGE PLANS MULTIPLE COMPLETION		COMMENCE DRII CASING TEST AN CEMENT JOB OTHER:	LLING OPNS.[PLUG AND 🔀 ABANDONMENT	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly sta	□ □ te all perti	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER:	LLING OPNS. ID Compared to the compared to t	PLUG AND ABANDONMENT See, including estimated date	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly sta	□ □ te all perti	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER:	LLING OPNS. ID Compared to the compared to t	PLUG AND ABANDONMENT Bes, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly state SEE RULE 1103. For Management of the state of	□ □ te all pertifultiple Co	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach	LLING OPNS. ID Compared to the compared to t	PLUG AND ABANDONMENT Bes, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly sta SEE RULE 1103. For M sxs Premium Plus, 2%6	te all pertifultiple Co	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach	LLING OPNS. ID Compared to the compared to t	PLUG AND ABANDONMENT Bes, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Management of Section 1988). Test plug to 390 psi.	te all pertitultiple Co	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach	LLING OPNS. ID Compared to the compared to t	PLUG AND ABANDONMENT Bes, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 1	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Management of Section 1988). Test plug to 390 psi. 100 bbls 10# 35 vis. Mud.	te all pertitultiple Co	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER: inent details, and giv ompletions: Attach	LLING OPNS.[ID [PLUG AND ABANDONMENT Bes, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 18 RIH w/ tbg to 2821' spot cmt to 2292	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Management of Section 1988). Test plug to 390 psi. 100 bbls 10# 35 vis. Mud.	te all pertitultiple Co	COMMENCE DRII CASING TEST AN CEMENT JOB OTHER: inent details, and giv ompletions: Attach	LLING OPNS.[ID [PLUG AND ABANDONMENT Bes, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292 RIH to tag TOC @ 2292'.	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Market SEE R	te all pertitultiple Co	COMMENCE DRIE CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach ppg. in 30 min. d Shut down over ni	LLING OPNS. ID The pertinent date wellbore diagram ight.	PLUG AND ABANDONMENT es, including estimated date m of proposed completion or	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 18 RIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RRIH w/ cmt Retainer to set @ 1221'.	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Market SEE R	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach ppg. in 30 min. d Shut down over no 52.25 bpm @ 1450 p 1.5 bpm, 1290 psi.	LLING OPNS. ID The pertinent date wellbore diagrating diagrams of the control o	PLUG AND ABANDONMENT es, including estimated date m of proposed completion or again	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 18 RIH w/ tbg to 2821' spot cmt to 2292 RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For March 1103. For March 1104 1105. For March 1104 1105. For March 1104 1105. For March 1104 1105. For March 1105. For March 1106. For March	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach of the second se	LLING OPNS. ID /e pertinent date wellbore diagra ight. psi POOH w/ p then shut down	PLUG AND ABANDONMENT es, including estimated date m of proposed completion or again	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 18 RIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic states of the second	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach of the second se	LLING OPNS. ID /e pertinent date wellbore diagra ight. psi POOH w/ p then shut down	PLUG AND ABANDONMENT es, including estimated date m of proposed completion or again	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RRIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½" csg. Cap and install PA	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic states of the second	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach of ppg. in 30 min. d Shut down over no 52.25 bpm @ 1450 p 1.5 bpm, 1290 psi. 10# 35 vis mud. w/ cmt. Shut down over	re pertinent date wellbore diagra	PLUG AND ABANDONMENT Pes, including estimated date of proposed completion or \$\frac{900}{5900H} = \frac{9}{100} = \frac{900}{100} = \fra	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 18 RIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic states of the second	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach of ppg. in 30 min. d Shut down over no 52.25 bpm @ 1450 p 1.5 bpm, 1290 psi. 10# 35 vis mud. w/ cmt. Shut down over	re pertinent date wellbore diagra	PLUG AND ABANDONMENT Pes, including estimated date of proposed completion or \$\frac{900}{5900H} = \frac{9}{100} = \frac{900}{100} = \fra	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' R RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½" csg. Cap and install PA I hereby certify that the informat	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic states of the second	te all pertifultiple Co	COMMENCE DRIFE CASING TEST AND CEMENT JOB OTHER: Intent details, and give ompletions: Attach of the second	ight. POOH w/pthen shut down over night.	PLUG AND ABANDONMENT Pes, including estimated date m of proposed completion or squoth O31. Dacker 1. Pressure held	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RRIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½" csg. Cap and install PA	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic See Rule 1103. For Ma	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach of ppg. in 30 min. d Shut down over no 52.25 bpm @ 1450 p 1.5 bpm, 1290 psi. 10# 35 vis mud. w/ cmt. Shut down over	ight. POOH w/p then shut down over night. The degree and belief an	PLUG AND ABANDONMENT Pes, including estimated date m of proposed completion or squoth CALL. DATE: Dec. 12, 04	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ 18 RIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' R RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½" csg. Cap and install PA I hereby certify that the informat	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic See Rule 1103. For Ma	te all pertifultiple Co	COMMENCE DRIFE CASING TEST AND CEMENT JOB OTHER: Intent details, and give ompletions: Attach of the second	ight. POOH w/p then shut down over night. The degree and belief an	PLUG AND ABANDONMENT Pes, including estimated date m of proposed completion or squoth O31. Dacker 1. Pressure held	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½' csg. Cap and install PA I hereby certify that the informat SIGNATURE Type or print name: Darryl Reth	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly states SEE RULE 1103. For Magnetic See Rule 1103. For Ma	te all pertifultiple Co	COMMENCE DRIFE CASING TEST AND CEMENT JOB OTHER: Intent details, and give ompletions: Attach of the second	ight. POOH w/p then shut down over night. The degree and belief an	PLUG AND ABANDONMENT Pes, including estimated date m of proposed completion or squoth CALL. DATE: Dec. 12, 04	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' R RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½" csg. Cap and install PA I hereby certify that the informat SIGNATURE Type or print name: Darryl Reth (This space for State use)	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly state SEE RULE 1103. For Magnetic states of the second s	te all pertifultiple Co	COMMENCE DRIII CASING TEST AN CEMENT JOB OTHER: inent details, and give ompletions: Attach of the second of the se	ight. posi POOH w/pover night. edge and belief an Telep	PLUG AND ABANDONMENT Pes, including estimated date m of proposed completion or squoth squoth squoth no.: 505-396-7503	
TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 12. Describe proposed or completed of starting any proposed work). recompilation. Set CIBP @ 4703' it would not test Set second CIBP @ 4670' cap w/ 30 Tag TOC @ 4368' Set Packer @ 435 Release pkr. Circulate to surface w/ IRIH w/ tbg to 2821' spot cmt to 2292' RIH to tag TOC @ 2292'. Perforate 4 Squeeze holes @ 2030' R RIH w/ cmt Retainer to set @ 1221'. Sting out of retainer and spot 35' cmt Spot cmt from 396' to surface. Pooh Cut off 5 ½" csg. Cap and install PA I hereby certify that the informat SIGNATURE Type or print name: Darryl Reth (This space for State use)	CHANGE PLANS MULTIPLE COMPLETION d operations. (Clearly state SEE RULE 1103. For Magnetic states of the second s	te all pertifultiple Co	COMMENCE DRIFE CASING TEST AND CEMENT JOB OTHER: Intent details, and give ompletions: Attach of the second	ight. posi POOH w/pover night. edge and belief an Telep	PLUG AND ABANDONMENT Pes, including estimated date m of proposed completion or squoth squoth squoth no.: 505-396-7503	

Approved as to plugging of the Well Bore. Liability under bond is retained until surface restoration is completed.

