Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103
District I Energy 1625 N. French Dr., Hobbs, NM 88240	y, Minerals and Natural Resources	March 4, 2004 WELL API NO.
District II		30-025-02207
	CONSERVATION DIVISION	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE 🗹 FEE
District IV 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
87505		B-871-1
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A		7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		West Vacuum Unit
PROPOSALS.)	, , , , , , , , , , , , , , , , , , ,	8. Well Number
1. Type of Well: Oil Well Gas Well Other		
2. Name of Operator		19
2. Name of Operator Chevron USA Inc		9. OGRID Number
3. Address of Operator		10. Pool name or Wildcat
15 Smith Rd, Midland,	TX 79705	Vacuum Grayburg San Andres
4. Well Location		radum orayburg dan Andres
F 4000		
Unit Letter F : 1980 f	eet from the <u>N</u> line and	1980 feet from the West line
Section 34		
Section	Township 17-S Range 34-E ion (Show whether DR, RKB, RT, GR, etc	NMPM Lea County
	ion (Snow whether DR, KKB, KI, GR, eld	
Pit or Below-grade Tank Application (For pit or below-g	rade tank closures, a form C-144 must be attack	ed)
Pit Location: UL_F_Sect_34_Twp_17S_Rng_34E	Pit type Steel Depth to Groundwater	87 Distance from nearest fresh water well Over 1000'
Distance from nearest surface water Below-g		
1980 feet from the <u>N</u> line and <u>1980</u> feet fro		
		7 7 89
12. Check Appropriate	e Box to Indicate Nature of Notice	, Report or Other Data
12. Check Appropriate NOTICE OF INTENTION	ITO: SUE	
12. Check Appropriate NOTICE OF INTENTION		
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND	ATO: SUI	
12. Check Appropriate NOTICE OF INTENTION	ATO: SUI	
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE	I TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DR E CASING TEST A	
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE	I TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DR E CASING TEST A	
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET	A TO: SUE D ABANDON D REMEDIAL WOR PLANS D COMMENCE DE CASING TEST A CEMENT JOB	
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER:	A TO: SUE D ABANDON D REMEDIAL WOR PLANS D COMMENCE DR CASING TEST A CEMENT JOB D OTHER:	ABANDONMENT
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE OTHER: 13. Describe proposed or completed operation	I TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF E CASING TEST A TION CHER: Dons. (Clearly state all pertinent details, and compared by state all pertinent details.	ABANDONMENT
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU	I TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF E CASING TEST A TION CHER: Dons. (Clearly state all pertinent details, and compared by state all pertinent details.	ABANDONMENT
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COTHER: 13. Describe proposed or completed operation or recompletion. 1. Notified OCD with P&A intent.	I TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF E CASING TEST A CEMENT JOB OTHER: Dons. (Clearly state all pertinent details, and JLE 1103. For Multiple Completions: A 6. Perf.	ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING OPO
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COTHER: 13. Describe proposed or completed operation or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40	I TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF ION CASING TEST A CEMENT JOB OTHER: ION. OTHER: ION. OTHER: IDIS. (Clearly state all pertinent details, and JLE 1103. For Multiple Completions: A 130-3900 (San Andres) WOC Tag 6. Perf	ABANDONMENT
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835.	N TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DR E CASING TEST A CEMENT JOB OTHER: Dons. (Clearly state all pertinent details, at JLE 1103. For Multiple Completions: A 130-3900 (San Andres) WOC Tag	ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING CASING ALTERING CASING ALTERING OPNS. PLUG AND ALTERING CASING ALTERING ALTERING CASING ALTERING
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND TEMPORARILY ABANDON □ CHANGE PULL OR ALTER CASING □ MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800	I TO: SUI D ABANDON I PLANS COMMENCE DF E CASING TEST A CEMENT JOB OTHER: ION OTHER: OSTAR OTHER: OSTAR OTHER: ION OTHER: ION OTHER: ION OTHER: ION OTHER: IOSO-3900 (San Andres) WOC Tag 6. Perf WO III PBBL. -2600(Yates B-salt)WOC Tag @ 2610'	ALTERING CASING ALTERING ALTERING CASING ALTERING ALTER
 12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# salt g 	I TO: SUI D ABANDON I PLANS COMMENCE DF E CASING TEST A CEMENT JOB OTHER: ION OTHER: OSTAR OTHER: OSTAR OTHER: ION OTHER: ION OTHER: ION OTHER: ION OTHER: IOSO-3900 (San Andres) WOC Tag 6. Perf WO III PBBL. -2600(Yates B-salt)WOC Tag @ 2610'	Aboles at 300, sqz 190sx, Circ cmt to Surf C Tag at Surf. Il dry hole marker 12-23-04. Approved as to plugging of the Well Bore.
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND TEMPORARILY ABANDON □ CHANGE PULL OR ALTER CASING □ MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# salt g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: OOS. OTHER: OOS. OTHER: OS. Glearly state all pertinent details, and JLE 1103. For Multiple Completions: A BL -2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153	ALTERING CASING ALTERING ALTERING CASING ALTERING CASING ALTERING ALTERING ALTERING CASING ALTERING ALTE
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND TEMPORARILY ABANDON □ CHANGE PULL OR ALTER CASING □ MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operatio of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: OOS. OTHER: OOS. OTHER: OS. OS. Sando:San Andres) WOC Tag @ 2610' 1550(Stub,8 5/8 shoe,T-salt) MOC Tag @ 153 and complete to the best of my knowled OTHER:	ALTERING CASING ALTERING ALTERING CASING ALTERING ALTERING CASING ALTERING A
 12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 13. Notified OCD with P&A intent. 14. RiH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# salt g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725 7. I hereby certify that the information above is true grade tank has been/will be constructed or closed according 	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: ODS. (Clearly state all pertinent details, and JLE 1103. For Multiple Completions: A Barborn State 6. Perf WOI 7. Instant el P/BBL. -2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled ag to NMOCD guidelines [], a general permit []	ALTERING CASING ALTERING OPNS. PLUG AND ALTERING CASING ALTERING AND ALTERING CASING ALTERNATION ALTERING CASING ALTERNATION ALTERNATI
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK □ PLUG AND TEMPORARILY ABANDON □ CHANGE PULL OR ALTER CASING □ MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: OOS. OTHER: OOS. OTHER: OS. OS. Sando:San Andres) WOC Tag @ 2610' 1550(Stub,8 5/8 shoe,T-salt) MOC Tag @ 153 and complete to the best of my knowled OTHER:	ALTERING CASING ALTERING OPNS. PLUG AND ALTERING CASING ALTERING AND ALTERING CASING ALTERNATION ALTERING CASING ALTERNATION ALTERNATI
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725 I hereby certify that the information above is true grade tank has been/will be constructed or closed according	N TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB TION OTHER: Dons. (Clearly state all pertinent details, at JLE 1103. For Multiple Completions: A Gasobase P/BBL. -2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled ng to NMOCD guidelines [], a general permit []	ALTERING CASING ALTERING AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING CASING ALTERING AND ALTERING CASING ALTERING CASING ALTERING AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING
 12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 14. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# salt g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725 1 hereby certify that the information above is true grade tank has been/will be constructed or closed according 	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CASING TEST A CEMENT JOB OTHER: DOS. (Clearly state all pertinent details, at JLE 1103. For Multiple Completions: A B30-3900 (San Andres) WOC Tag el P/BBL. -2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled ng to NMOCD guidelines [], a general permit []	ALTERING CASING ALTERING AND ALTERING CASING ALTERING CASING ALTERING AND ALTERING CASING ALTERING CASING ALTERING AND ALTERING CASING ALTERING AND ALTERING AND ALTERING CASING AND ALTERING CASING AND ALTERING AND ALTERING CASING AND ALTERING AND ALTERING AND ALTERING AND ALTERING AND ALTERING AND ALTERING ALTERING AND ALTERING
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/7250 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725 I hereby certify that the information above is true grade tank has been/will be constructed or closed according SIGNATURE Type or print name Jimmy Bagley	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: OOTHER: OTHER: Dons. (Clearly state all pertinent details, and JLE 1103. For Multiple Completions: A Baber P/BBL. -2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled and complete to the best of my knowled TITLE Consulta E-mail address:	ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING OPNS. PLUG AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING ALTERING ALTERING AND ALTERING
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/2800 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725 I hereby certify that the information above is true grade tank has been/will be constructed or closed according SIGNATURE	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: OOTHER: OTHER: Dons. (Clearly state all pertinent details, and JLE 1103. For Multiple Completions: A Gastron Multiple Completions: A BL-2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled and complete to the best of my knowled TITLE Consulta E-mail address:	ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ALTERING OPNS. PLUG AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING AND ALTERING CASING ALTERING ALTERING ALTERING AND ALTERING
 Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET PULL OR ALTER CASING MULTIPLE COMPLET Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. Notified OCD with P&A intent. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. Displace hole w/MLF, 9.5# Brine w/12.5# salt g Perf 4 holes @ 2800 sqz 50sx cmt plug fr/1725 I hereby certify that the information above is true grade tank has been/will be constructed or closed according SIGNATURE Type or print name This space for State use) 	ITO: SUE DABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB ION OTHER: Dons. (Clearly state all pertinent details, at JLE 1103. For Multiple Completions: A P30-3900 (San Andres) WOC Tag 6. Perf PBBL. -2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled ag to NMOCD guidelines [], a general permit [] TITLE Consultation	ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING OPNS. ALTERING OPNS. ALTERING AND ALTERING AND ALTERING OPNS. ALTERING AND
12. Check Appropriate NOTICE OF INTENTION PERFORM REMEDIAL WORK PLUG AND TEMPORARILY ABANDON CHANGE PULL OR ALTER CASING MULTIPLE COMPLET OTHER: 13. Describe proposed or completed operation of starting any proposed work). SEE RU or recompletion. 1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4030, spot 25sx, plug from 40 at 3835. 3. Displace hole w/MLF, 9.5# Brine w/12.5# sait g 4. Perf 4 holes @ 2800 sqz 50sx cmt plug fr/7250 5. Perf 4 holes @ 1725 sqz 75sx cmt plug fr/1725 I hereby certify that the information above is true grade tank has been/will be constructed or closed according SIGNATURE Type or print name Jimmy Bagley	A TO: SUI D ABANDON REMEDIAL WOI PLANS COMMENCE DF CASING TEST A CEMENT JOB CON OTHER: OOTHER: OTHER: Dons. (Clearly state all pertinent details, and JLE 1103. For Multiple Completions: A Gastron Multiple Completions: A BL-2600(Yates,B-salt)WOC Tag @ 2610' -1550(Stub,8 5/8 shoe,T-salt)WOC Tag @ 153 and complete to the best of my knowled and complete to the best of my knowled TITLE Consulta E-mail address:	ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING CASING ALTERING CASING ALTERING OPNS. ALTERING OPNS. ALTERING OPNS. ALTERING AND ALTERING AND ALTERING OPNS. ALTERING AND

.

8