

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate
(Other instructions on
reverse side)COPY TO C. C. C.
Form approved.

Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM LC - 067968 0349952

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

W. Dollarhide Drinkard Unit

8. FARM OR LEASE NAME

W. Dollarhide Drinkard Unit

9. WELL NO.

7

10. FIELD AND POOL, OR WILDCAT

Dollarhide Tubb-Drinkard

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

19-248-38E

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Skelly Oil Company

3. ADDRESS OF OPERATOR

P. O. Box 730, Hobbs, New Mexico 88240-1088, NEW MEXICO.

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1650' PSL & 1980' FEL Sec. 19-248-38E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

Unknown

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Convert to water injection

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1) Move in and rig up pulling unit.

2) Pull rods and tubing.

3) Run tubing and set packer.

4) Rig down and connect to injection system.

After reservoir begins to pressure up, then:

5) Rig up pulling unit and pull tubing and packer.

6) Run tubing with bit and clean out to T.D.

7) Pull tubing and bit.

8) Run tubing and set packer.

9) Fill annulus with inhibited fluid.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Production Mgr.

DATE

7-15-69

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APPROVED

JUL 16 1969
ARTHUR R. BROWN
DISTRICT ENGINEER