## State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 5-27-2004

	OIL CONSEIN F	ATION DIVISION			
DISTRICT I 1625 N. French Dr., Hobbs, NM 88240		St. Francis Dr. NM 87505	WELL API NO. 30-025-	05481	
DISTRICT II	,		5. Indicate Type of Lease		
1301 W. Grand Ave, Artesia, NM 88210			STATE X	FEE	
DISTRICT III			6. State Oil & Gas Lease No.		
1000 Rio Brazos Rd, Aztec, NM 87410					
	TICES AND REPORTS ON WEI	LS	7. Lease Name or Unit Agreeme	ent Name	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			NORTH HORRS (G/SA) I	NORTH HOBBS (G/SA) UNIT	
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (Form C-101) for such proposals.)		Section 24			
1. Type of Well:	TI DIONITION TOWN DIE		8. Well No. 311		
Oil Well	Gas Well Other In	iector			
Oil Well Gas Well Other Injector  2. Name of Operator			9. OGRID No. 157984		
Occidental Permian Ltd.					
3. Address of Operator			10. Pool name or Wildcat	HOBBS (G/SA)	
1017 W. Stanolind Rd., HOBBS,	NM 88240 505/39	7-8200		` ′	
4. Well Location					
Unit Letter B : 660	Feet From The NORTH	1980 Fee	et From The EAST	Line	
Section 24	Township 18-S	Range 37-	E NMPM	LEA County	
	11. Elevation (Show whether DF, RK 3662' GR	(B, RT GR, etc.)			
Pit or Below-grade Tank Application	or Closure				
Pit Type Depth of Ground	d Water Distance from n	earest fresh water well	Distance from nearest sur	face water	
Pit Liner Thickness mil	Below-Grade Tank: Volume	bbls; Construction Ma	aterial		
12. Chec	k Appropriate Box to Indicate Na	ture of Notice, Report, or	Other Data		
NOTICE OF INT			SEQUENT REPORT OF	<b>:</b>	
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERING	CASING	
FERI ORIVINEDIAL WORK	1 EGG MID ADMIDON	TALIMEDIAE WORK			
	01141105 BL4110	COMMENCE DRILLING OF	NO DILICOA	BANDONIMENT -	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OF		BANDONMENT	
TEMPORARILY ABANDON PULL OR ALTER CASING	CHANGE PLANS Multiple Completion	COMMENCE DRILLING OF CASING TEST AND CEME		BANDONMENT	
<u> </u>		CASING TEST AND CEME	NT JOB	BANDONMENT X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Op	Multiple Completion	CASING TEST AND CEME OTHER: Convert we etails, and give pertinent date	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject	Multiple Completion  Deterations (Clearly state all pertinent defendance)  For Multiple Completions: Attach w	CASING TEST AND CEME OTHER: Convert we etails, and give pertinent date	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.	Multiple Completion  Deterations (Clearly state all pertinent defendance)  For Multiple Completions: Attach was ion equipment.	CASING TEST AND CEMER OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210	Multiple Completion  Derations (Clearly state all pertinent derections) For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.	Multiple Completion  Derations (Clearly state all pertinent derections)  For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.	Multiple Completion  Derations (Clearly state all pertinent derections)  For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.	Multiple Completion  Derations (Clearly state all pertinent derections)  For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.	Multiple Completion  Derations (Clearly state all pertinent derections)  For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.	Multiple Completion  Derations (Clearly state all pertinent derections)  For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.  Rig Up Date: 11/22/2004	Multiple Completion  Derations (Clearly state all pertinent derections)  For Multiple Completions: Attach we ion equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMEL OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed	NT JOB	X	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.  Rig Up Date: 11/22/2004  Rig Down Date: 11/30/2004	Multiple Completion  Decrations (Clearly state all pertinent defer Multiple Completions: Attach with the equipment.  15% NEFE HCL acid. 1000# RS is 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMER OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed like set @3946'.	ell to Producer s, including estimated date of st completion or recompletion.	arting any	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.  Rig Up Date: 11/22/2004  Rig Down Date: 11/30/2004	Multiple Completion  Derations (Clearly state all pertinent der For Multiple Completions: Attach was ion equipment.  If a significant of the state o	CASING TEST AND CEMER OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed like set @3946'.	ell to Producer s, including estimated date of st completion or recompletion.	arting any	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.  Rig Up Date: 11/22/2004  Rig Down Date: 11/30/2004	Multiple Completion  Derations (Clearly state all pertinent der For Multiple Completions: Attach was ion equipment.  If a significant of the state o	CASING TEST AND CEMER OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed like set @3946'.	ell to Producer s, including estimated date of st completion or recompletion.	arting any	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.  Rig Up Date: 11/22/2004  Rig Down Date: 11/30/2004	Multiple Completion  Derations (Clearly state all pertinent der For Multiple Completions: Attach was ion equipment.  If a significant of the state o	CASING TEST AND CEMER OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed where the etails are diagram of an are diagram of a second of the etails.	ell to Producer s, including estimated date of st completion or recompletion.	arting any  as been/will be	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12: 5. Install QCI wellhead connections 6. RDPU. Clean Location.  Rig Up Date: 11/22/2004 Rig Down Date: 11/30/2004  Thereby certify that the information above is constructed or closed according to NMOCD guidelines.	Multiple Completion  perations (Clearly state all pertinent de For Multiple Completions: Attach with the equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	CASING TEST AND CEMER OTHER: Convert we etails, and give pertinent date wellbore diagram of proposed where the etails are diagram of an are diagram of a second of the etails.	ell to Producer s, including estimated date of st completion or recompletion.  y that any pit or below-grade tank have OCD-approved	arting any  as been/will be	
PULL OR ALTER CASING  OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12.  5. Install QCI wellhead connection.  6. RDPU. Clean Location.  Rig Up Date: 11/22/2004 Rig Down Date: 11/30/2004  I hereby certify that the information above is constructed or closed according to NMOCD guidelines.  SIGNATURE	Multiple Completion  perations (Clearly state all pertinent de For Multiple Completions: Attach with the equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	casing test and cemel other:  Convert we etails, and give pertinent date wellbore diagram of proposed like set @3946'.  Tedge and belief. I further certify or an (attached) alternative plan  TITLE Workover Comrobert gilbert@oxy.com	ell to Producer  s, including estimated date of st completion or recompletion.  y that any pit or below-grade tank have OCD-approved  appletion Specialist  TELEPHONE NO.	arting any  2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	
PULL OR ALTER CASING OTHER:  13. Describe Proposed or Completed Or proposed work) SEE RULE 1103.  1. RUPU. Pull and lay down inject 2. Clean out w/bit to 4276'.  3. Stimulate perfs 4200-56 w/2210  4. RIH Reda ESP equipment on 12: 5. Install QCI wellhead connection. 6. RDPU. Clean Location.  Rig Up Date: 11/22/2004 Rig Down Date: 11/30/2004  I hereby certify that the information above is constructed or closed according to NMOCD guidelines  SIGNATURE  TYPE OR PRINT NAME Robert Gilb.	Multiple Completion  perations (Clearly state all pertinent de For Multiple Completions: Attach with the equipment.  g 15% NEFE HCL acid. 1000# RS 3 jts 2-7/8" tbg w/drain valve. Inta	casing test and cemel other:  Convert we etails, and give pertinent date wellbore diagram of proposed like set @3946'.  Tedge and belief. I further certify or an (attached) alternative plan  TITLE Workover Comrobert gilbert@oxy.com	ell to Producer  s, including estimated date of st completion or recompletion.  y that any pit or below-grade tank have OCD-approved  appletion Specialist  DATE	arting any  2 2 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	