Submit 3 Copies To Appropriate District State of New Mexico	Form C-103
Office Energy, Minerals and Natural Resources	March 4, 2004
District.I 1625 N. French Dr., Hobbs, NM 87240	WELL API NO.
District II 1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION	<u>30-025-36596</u>
District III 1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 District IV	STATE <b>x</b> FEE
1220 S. St. Francis Dr., Santa Fe, NM 87505	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name:
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	Straw Hat 6 State
1. Type of Well: Oil Well Gas Well X Other	8. Well Number
2. Name of Operator	9. OGRID Number
EOG Resources Inc.	7377
3. Address of Operator	10. Pool name or Wildcat
P.O. Box 2267 Midland, Texas 79702	Hat Mesa; Morrow (Gas)
4. Well Location	·
Limit Latton F , 2010 foot from the Courth line of t	
Unit Letter <b>F</b> : <b>3819</b> feet from the <b>South</b> line and	<b></b> feet from the <u></u>
Section 6 Township 21S Range 33E	NMPM County Lea
11. Elevation (Show whether DR, RKB, RT, GR, et	<i>c.)</i>
3777' GR	
Pit or Below-grade Tank Application (For pit or below-grade tank closures, a form C-144 must be attache	
Pit location: UL Sect Twp Rng Pit type Depth to Groundwater	Distance from nearest fresh water well
Distance from nearest surface water Below-grade Tank Location UL Sect	_ Twp Rng;
feet from the line and feet from the line	
12. Check Appropriate Box to Indicate Nature of Notice,	
12. ULEUK AUDIODHALE DOX IO HULCALEUNAHITE OF NODCE	
	•
NOTICE OF INTENTION TO: SUB	SEQUENT REPORTOF
	SEQUENT REPORTOF
NOTICE OF INTENTION TO: SUB	
NOTICE OF INTENTION TO: SUB	SEQUENT REPORT OF:
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB	SEQUENT REPORT OF:
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: Comp	SEQUENT REPORT OF:
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB	SEQUENT REPORT-OF: ALTERING CASING ING OPNS. PLUG AND ABANDONMENTS ABANDON ABANDONMENTS ABANDON ABANDON ABANDON ABANDON ABANDON
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and g of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attack or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H	SEQUENT REPORT-OF: ALTERING CASING NG OPNS. NG OPNS. NG OPNS. ALTERING CASING PLUG AND ABANDONMENT ABANDONMENT ABANDONMENT ALTERING CASING ALTERING CASING ABANDONMENT ABANDONMENT ALTERING CASING ALTERING CASING ALTERNA
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and go of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.	SEQUENT REPORT-OF: ALTERING CASING NG OPNS. NG OPNS. ABANDONMENTS ABANDON
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and go of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class	SEQUENT REPORT OF: ALTERING CASING NG OPNS. NG OPNS. ABANDONMENTS ABANDON ABANDONMENTS ABANDON ABAN
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: Completed operations. (Clearly state all pertinent details, and go of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365	SEQUENT REPORT OF: ALTERING CASING NG OPNS. NG OPNS. ABANDONMENTS ABANDON ABANDONMENTS ABANDON ABAN
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: COMPLETION   13. Describe proposed or completed operations. (Clearly state all pertinent details, and yof starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.	SEQUENT REPORT OF: ALTERING CASING NG OPNS. NG OPNS. ABANDONMENTS ABANDON ABANDONMENTS ABANDON ABA
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: COMPLETION   13. Describe proposed or completed operations. (Clearly state all pertinent details, and go f starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.	SEQUENT REPORT OF: ALTERING CASING NG OPNS. NG OPNS. ABANDONMENTS ABANDON ABANDONMENTS ABANDON ABA
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: CASING TEST AND CEMENT JOB   13. Describe proposed or completed operations. (Clearly state all pertinent details, and g of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. OTHER: Completion:   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface. 7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'.	SEQUENT REPORT OF: ALTERING CASING NG OPNS. NG OPNS. ABANDONMENTS ABANDON ABANDONMENTS ABANDON ABA
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: Completed operations. (Clearly state all pertinent details, and pof starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04   7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'. test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge.	SEQUENT REPORT OF: AttERING CASING NG OPNS. PLUG AND ABANDONMENTS ABANDON A
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: CASING TEST AND CEMENT JOB   13. Describe proposed or completed operations. (Clearly state all pertinent details, and g of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. OTHER: Completion:   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface. 7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'.	SEQUENT REPORT OF: AttERING CASING NG OPNS. PLUG AND ABANDONMENTS ABANDON A
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: CASING TEST AND CEMENT JOB   13. Describe proposed or completed operations. (Clearly state all pertinent details, and y of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04   7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'. test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will be constructed or closed according to NMOCD guidelines	SEQUENT REPORT OF: AttERING CASING NG OPNS. PLUG AND ABANDONMENTS ABANDON ABAND
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: Completed operations. (Clearly state all pertinent details, and point of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion.   6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'. test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will % constructed or closed according to NMOCD guidelines, a general permit   SIGNATURE TITLE Regulato E-mail address:	SEQUENT REPORT OF: AttERING CASING NG OPNS. PLUG AND ABANDONMENTS ABANDON A
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and g of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attack or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 H and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will te constructed or closed according to NMOCD guidelines, a general permit   SIGNATURE TITLE Regulator E-mail address:	SEQUENT REPORT OF: AttERING CASING NG OPNS. PLUG AND ABANDONMENTS ABANDON ABAND
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and a of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 M and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'. test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will te constructed or closed according to NMOCD guidelines, a general permit   SIGNATURE Umapper   This space for State use) THE	SEQUENT REPORT OF: ALTERING CASING NG OPNS. PLUG AND ABANDONMENTS ALTERING CASING PLUG AND ABANDONMENTS ALTERING CASING ABANDONMENTS ALTERING CASING ABANDONMENTS ALTERING CASING ALTERING CASING ALTERNO ALTER
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and a of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 M and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'. test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will te constructed or closed according to NMOCD guidelines, a general permit   SIGNATURE Umapper   This space for State use) THE	SEQUENT REPORT OF: ALTERING CASING NG OPNS. PLUG AND ABANDONMENTS ALTERING CASING PLUG AND ABANDONMENTS ALTERING CASING ABANDONMENTS ALTERING CASING ABANDONMENTS ALTERING CASING ALTERING CASING ALTERNO ALTER
NOTICE OF INTENTION TO: SUB   PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK   TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILL   PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST AND CEMENT JOB   OTHER: OTHER: OTHER: OTHER:   13. Describe proposed or completed operations. (Clearly state all pertinent details, and a of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompletion. 6/30/04 RIH w/ casing squeeze gun and perforate @ 3800'- 3801', 4 M and circulate 9 5/8" X 5 1/2" annulus to surface.   7/01/04 Squeezed 405 sx 50/50 POZ lead cement, tail w/ 100 sx Class 7/02/04 RIH & tag cement @ 3652'. Drill out cement & plug from 365 and pressure test casing to 1000 psi. Test good.   7/03/04 TIH w/ bit to DV tool @ 8484'. Drill out DV tool @ 8485'. test casing to 1000 psi. Test good.   Thereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will te constructed or closed according to NMOCD guidelines, a general permit   SIGNATURE Umapper   This space for State use) THE	SEQUENT REPORT OF: AtTERING CASING NG OPNS. PLUG AND ABANDONMENTS ABANDON