Submit 1 Copy To Appropriate District State of New Mexico	Form C-103 Revised August 1, 2011	
District I – (575) 393-6161 Energy, Minerals and Natural Resources	WELL API NO. 30-025-38035	
District II - (575) 748-1283 811 S First St., Artesia, NM 88210	5. Indicate Type of Lease	
811 S First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410 South St. Francis Dr. South St. Francis Dr.	STATE FEE	
$\frac{\text{District IV}}{1220 \text{ S st. Francis Dr., Santa Fe, NM JAN 19 2012}}$ Santa Fe, NM <b>87505</b>	6. State Oil & Gas Lease No.	
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOSEDENTED BILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		
PROPOSALS.)	ARMADILLO STATE 8. Well Number 1	
1. Type of Well: Oil Well 🛛 Gas Well 🗌 Other	9. OGRID Number	
2. Name of Operator PURVIS OPERATING CO.	131559	
3. Address of Operator PO BOX 51990, MIDLAND, TX 79710-1990	10. Pool name or Wildcat Mississi poian MORTON (WOLFCAMP)	
4. Well Location		
	feet from the <u>West</u> line	
Section 8         Township         15S         Range         35E         NMPM         Lea         County           11. Elevation (Show whether DR, RKB, RT, GR, etc.)         11. Elevation (Show whether DR, RKB, RT, GR, etc.)         11. Elevation (Show whether DR, RKB, RT, GR, etc.)         11. Elevation (Show whether DR, RKB, RT, GR, etc.)		
4032' GL		
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL WORK FEMPORARILY ABANDON  CHANGE PLANS FEMPORARILY ABANDON		
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB		
OTHER: OTHER:	П	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of		
proposed completion or recompletion.		
1-12-2012 Measure depth of hole at 45' with steel tape. Fill spud hole w/15 yds. of ready mix cement from 45' back to surface. Install dry hole marker. Well is P&A.		
cement from 45 back to surface. Install dry hole marker, weins have		
Approved for plugging of well bore only.		
the state sound as hand is retained being sound is		
bill the second of the second		
Forms, www.em	nrd.state.iim.us/ocd.	
Spud Date: December 22, 2006 Rig Release Date: Decem	mber 27, 1011	
Spud Date: Rig Release Date: Boost		
I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNATURE DATE January 17, 2012		
Type or print name Donnie E. Brown E-mail address: eng@purvisop.com PHONE: 432-682-7346         For State Use Only		
For State Use Only		
APPROVED BY: Mahuhhhhh TITLE Compliance Off Conditions of Approval (if any):	DATE 1-20-2012	

JAN 2 4 2012	T Ook
--------------	-------