	ate District	State of New Mexico	Form C-103		
Office <u>District I</u> – (575) 393-6161	HODRO Energy,	Minerals and Natural Resources	Revised August 1, 2011		
			WELL API NO.		
District II - (575) 748-1283 811 S. First St., Artesia, NM 88210 District III - (505) 334-6178 JAN 1 9 2012 CONSERVATION DIVISION 1220 South St. Francis Dr.			30-025-38037		
District III – (505) 334-6178	3 882 10 JAN 1 9 2012 12	220 South St. Francis Dr.	5. Indicate Type of Lease		
1000 Rio Brazos Rd., Aztec	, NM 87410	Santa Fe, NM 87505	STATE FEE		
District IV - (505) 476-3460)	Santa Fe, NWI 67303	6. State Oil & Gas Lease No.		
1220 S St. Francis Dr., Sant 87505	ta Fe, NM RECEIVED		V-6559 and VB-0563-1		
	NDRY NOTICES AND RE	EPORTS ON WELLS	7. Lease Name or Unit Agreement Name		
(DO NOT USE THIS FORM	M FOR PROPOSALS TO DRILL	OR TO DEEPEN OR PLUG BACK TO A			
	. USE "APPLICATION FOR PE	RMIT" (FORM C-101) FOR SUCH	COYOTE STATE COM		
PROPOSALS.) 1. Type of Well: Oil	Well ⊠ Gas Well □	Other	8. Well Number 1		
2. Name of Operator	Wen		9. OGRID Number		
	ERATING CO.		131559		
3. Address of Operato			10. Pool name or Wildcat		
PO BOX 51990, MIDLAND, TX 79710-1990			MORTON (WOLFCAMP)		
4. Well Location					
Unit Letter D : 990 feet from the North line and 1316 feet from the West line					
Section 8	Townshi		NMPM Lea County		
The section of		on (Show whether DR, RKB, RT, GR, etc.			
		29' GR			
To The Property of the State of	る場合は影響性の形式であった。	20 011	APP 1992 1994年 1994年 1995年 1995年		
1/	Charle Ammandata	Day to Indicate Nature of Nation	Papart or Other Data		
12	2. Check Appropriate	Box to Indicate Nature of Notice,	Report of Other Data		
NOTI	CE OF INTENTION	TO: SUP	SEQUENT REPORT OF:		
PERFORM REMEDIA		_			
TEMPORARILY ABAN	_		ILLING OPNS. □ P AND A □		
	<u> </u>	_	<u>—</u>		
PULL OR ALTER CAS	<u> </u>	COMPL CASING/CLIMEN	11 30B		
DOWNHOLE COMMIN	NGLE [_]				
		OTHER: OTHER: Test San Andres for production			
OTHER:		OTHER: Test S	an Andres for production		
OTHER: 13. Describe propo	osed or completed operation	OTHER: Test Some OTHER:	an Andres for production If give pertinent dates, including estimated date		
13. Describe propo	osed or completed operation proposed work). SEE RU	ns. (Clearly state all pertinent details, an	d give pertinent dates, including estimated date		
13. Describe propo of starting any	osed or completed operation proposed work). SEE RUI deletion or recompletion.	OTHER: Test Sons. (Clearly state all pertinent details, and LE 19.15.7.14 NMAC. For Multiple Co	d give pertinent dates, including estimated date		
13. Describe propo of starting any	proposed work). SEE RUI	ns. (Clearly state all pertinent details, an	d give pertinent dates, including estimated date		
13. Describe propo of starting any proposed comp	proposed work). SEE RUI pletion or recompletion.	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co	nd give pertinent dates, including estimated date impletions: Attach wellbore diagram of		
13. Describe propo of starting any proposed comp	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co	nd give pertinent dates, including estimated date impletions: Attach wellbore diagram of water.		
13. Describe proposed starting any proposed comp 12-13-2011 12-16-2011	proposed work). SEE RUM pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur	d give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water.		
13. Describe proposed for starting any proposed comp 12-13-2011 12-16-2011 12-20-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls	d give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. water. Swab formation water with no show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011	proposed work). SEE RUM pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710	d give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. water. Swab formation water with no show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011	proposed work). SEE RUM pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal +	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls.	d give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. water. Swab formation water with no show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of fo	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls p with 35' of cement. Perforate 5710 30 balls.	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of fo	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls p with 35' of cement. Perforate 5710 30 balls.	d give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. water Swab formation water with no show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of fo	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls p with 35' of cement. Perforate 5710 30 balls.	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of fo	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls p with 35' of cement. Perforate 5710 30 balls.	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls p with 35' of cement. Perforate 5710 30 balls. ormation water. H w/RBP and set at 5695'. Swab for	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011 12-28-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of fo	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls p with 35' of cement. Perforate 5710 30 balls.	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Ormation water. H w/RBP and set at 5695'. Swab for	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-22-2011 12-23-2011 12-27-2011 12-28-2011	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Ormation water. H w/RBP and set at 5695'. Swab for	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20'		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date:	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Ormation water. H w/RBP and set at 5695'. Swab for Rig Release Date:	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date:	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Ormation water. H w/RBP and set at 5695'. Swab for	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date:	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Symmation water. H w/RBP and set at 5695'. Swab for Rig Release Date: July 28	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date:	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Ormation water. H w/RBP and set at 5695'. Swab for Rig Release Date:	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show.		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date:	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Till	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Symmetric branched by with 35'. Swab for Mr. H. w/RBP and set at 5695'. Swab for Rig Release Date: Rig Release Date:	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show. ge and belief. DATE January 17, 2012		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date: I hereby certify that the SIGNATURE Type or print name	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Til	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Symmation water. H w/RBP and set at 5695'. Swab for Rig Release Date: July 28	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show. 2011 ge and belief. DATE January 17, 2012		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date: I hereby certify that the	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Till	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Symmetric branched by with 35'. Swab for Mr. H. w/RBP and set at 5695'. Swab for Rig Release Date: Rig Release Date:	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show. ge and belief. DATE January 17, 2012		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date: I hereby certify that the SIGNATURE Type or print name For State Use Only	proposed work). SEE RUI pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Till	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls o with 35' of cement. Perforate 5710 30 balls. Symmetric branching water. H w/RBP and set at 5695'. Swab for Rig Release Date: Rig Release Date:	water. water. Swab formation water with no show. '-20' mation water at 48 bbl/hr. No show. ge and belief. DATE January 17, 2012 DHONE: 432-682-7346		
13. Describe proposed farting any proposed comp 12-13-2011 12-16-2011 12-20-2011 12-23-2011 12-27-2011 12-28-2011 Spud Date: I hereby certify that the SIGNATURE Type or print name	proposed work). SEE RUlp pletion or recompletion. Perf 6056'-74'. Acidize Perf 6014'-26'. Acidize Perf 5881'-90' and 5896 Set CIBP at 5830'. Cap Acidize with 1000 gal + Swab 24 bbls/hour of for Perforate 5657'-74'. Till June 18, 2011 information above is true at the properties of	ns. (Clearly state all pertinent details, an LE 19.15.7.14 NMAC. For Multiple Co w/1500 gal + 60 balls. Swab sulfur w/1000 gal + 35 balls. Swab sulfur 6'-99'. Acidize w/1000 gal + 40 balls with 35' of cement. Perforate 5710 30 balls. Symmetric branched by with 35'. Swab for Mr. H. w/RBP and set at 5695'. Swab for Rig Release Date: Rig Release Date:	ad give pertinent dates, including estimated date impletions: Attach wellbore diagram of water. water. Swab formation water with no show. '-20' rmation water at 48 bbl/hr. No show. ge and belief. DATE January 17, 2012		