

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT-" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

Oil Gas
☒ Well ☐ Well ☐ Other

2. Name of Operator

STRATA PRODUCTION COMPANY

3. Address and Telephone No.

**P. O. Box 1030
Roswell, New Mexico 88202-1030 505-622-1127**

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

**660' FSL & 2310' FEL
Section 15-22S-32E**

5. Lease Designation and Serial No.

NM-27805

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Lechuza Federal #3

9. API Well No.

30-025-31753

10. Field and Pool, or Exploratory Area

Livingston Ridge Delaware East

11. County or Parish, State

Lea County, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ OTHER

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Strata Production Company requests approval to plug and abandon the well in the following manner:

1. Spot 35' of cement on CIBP @ 7200'.
2. 200' Plug 4400 - 4700', 25 sacks, Tag Plug.
3. Top of Salt plug 900 - 1200', 25 sacks.
4. Plug 520 - 720', 25 sacks.
5. 30' plug at surface, 20 sacks.
6. Install dry hole marker.
7. Remove equipment.
8. Clean and rip location per BLM guidelines.

*Perforate @ 1200' & Squeeze With Sufficient Cement (120SX.)
To Have Solid Plug F/900-1200' - Tag
Perforate @ 7200' & Squeeze With Sufficient Cement (20SX.)
To Have Solid Plug F/520-720' - Tag*

14. I hereby certify that the foregoing is true and correct

Signed *David E. Glan*

Title **Production Records**

Date **05/24/2005**

(This space for Federal or State office use)

Approved by **DAVID E. GLAN**

Title **PETROLEUM ENGINEER**

Date **JUN 01 2005**

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

* See Instruction on Reverse Side

F3160-5

GWW

SEE ATTACHED FOR
CONDITIONS OF APPROVAL