

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/> WIW		5. LEASE DESIGNATION AND SERIAL NO. NM-016799	
2. NAME OF OPERATOR The Wiser Oil Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P.O. Box 2568 Hobbs, New Mexico 88241		7. UNIT AGREEMENT NAME Maljamar Grayburg Unit	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 1980' FNL & 660' FEL Unit NH		8. WELL NAME AND NO. 18	
		9. API WELL NO. 30-025-00463	
		10. FIELD AND POOL, OR WILDCAT Maljamar Grayburg San Andres	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 4-T17S-R32E	
14. PERMIT NO	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 4220' GL	12. COUNTY OR PARISH Lea	13. STATE NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☐
CHANGE PLANS ☐

(Other) Plug and Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT * ☐

(Other) _____

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser requests approval to Plug and Abandon the well by the procedure listed below.

Surface Casing: 8-5/8" set @ 313'

Production Casing: 5-1/2" set @ 4398' & 4-1/2" flush joint liner set @ 4218'

Perfs: 3972'-4124'

1. POH w/pkr. & tbg. Set CIBP @ 3900'.
2. Spot 50' plug on CIBP.
3. Tag cement plug.
4. Circulate abandonment mud.
5. Spot 50' cement plug @ 2230'.
6. Tag cement plug.
7. Spot 50' cement plug @ 1300'.
8. Tag cement plug.
9. Spot 50' cement plug to surface.
10. Install dry hole marker.
11. Clean location.

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

18. I hereby certify that the foregoing is true and correct.

SIGNED

J.M. Jones

TITLE

Prod. Supt.

DATE

April 1, 2003

(This space for Federal or State office use)

APPROVED BY

(ORIG. SGD.) DAVID R. GLASS

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APR 7 2003

*See Instruction On Reverse Side

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

GWV