District 1 – (575) 393-6161 Energy, Minerals and Natural Resources	Form C-103 Revised August 1, 2011
	WELL API NO.
	30-005-27945
OIL CONSERVATION DIVISION	5. Indicate Type of Lease
$\frac{\text{District III}}{1000 \text{ Rio Brazos Rd., Aztec, NM 87410}} 21 2013 \frac{1220 \text{ South St. Francis Dr.}}{\text{Santa Fe, NM 87505}}$	STATE S FEE
District IV – (505) 476-3460 MAY 2 1 C Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM	
87505 SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	Hominy 36 State
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other	8. Well Number / / / / / / / / / / / / / / / / / / /
2. Name of Operator TLT SWD, L.L.C.	9. OGRID Number / 287481
3. Address of Operator	10. Pool name or Wildcat
PO Box 1906 Hobbs,NM 88241	Anderson Ranch; Wolfcamp, North
4. Well Location	
Unit Letter O : 660 feet from the South line and 231	0 feet from the East line
	1E NMPM Chaves County
11. Elevation (Show whether DR, RKB, RT, GR, e.	
12. Check Appropriate Box to Indicate Nature of Notic NOTICE OF INTENTION TO: SU PERFORM REMEDIAL WORK □ PLUG AND ABANDON ⊠ REMEDIAL WOR	BSEQUENT REPORT OF:
TEMPORARILY ABANDON 🗌 CHANGE PLANS 🔲 COMMENCE D	RILLING OPNS. PAND A
PULL OR ALTER CASING 🔲 MULTIPLE COMPL 🔲 CASING/CEME	
OTHER: OTHER:	<u> </u>
12 Describe propagad or accordiant accordiant (Ol-1-1-1-1-1) - 1 - 1 - 1	
 Describe proposed or completed operations. (Clearly state all pertinent details, a of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. 	Completions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion.	
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows	Completions: Attach wellbore diagram of
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU	Completions: Attach wellbore diagram of Spot 255+ Cuitæ 8990
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas	Completions: Attach wellbore diagram of Spot 255+ Cunta 8990
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU	Completions: Attach wellbore diagram of Spot 255+ Cuitæ 8990
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet – Yates /Base of Salt 2453 feet	Completions: Attach wellbore diagram of $5p_0 + 25 \leq r$ Curter 8890 DV/7000 DV/7000
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f	Completions: Attach wellbore diagram of $5p_0 + 25 \leq r$ Curter 8890 DV/7000 DV/7000
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above	Completions: Attach wellbore diagram of $5p_0 + 25 \leq r$ Curter 8890 DV/7000 DV/7000
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above	Completions: Attach wellbore diagram of $5p_0 + 25 \leq r$ Curter 8890 DV/7000 DV/7000
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug	Completions: Attach wellbore diagram of $5p_0 + 25 \leq r$ Curter 8890 DV/7000 DV/7000
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above	Completions: Attach wellbore diagram of $5p_0 + 25 = -$ Curter 8890 DV/7000
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 25 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ The Oil Conserv	Completions: Attach wellbore diagram of Spot 25 st Conte 8890 DV/1000 Feet)
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ The Oil Conserv 24 hours prior to	Completions: Attach wellbore diagram of $5pot 25 \le r$ Conta 8890 DV/7000 Geet)
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ The Oil Conserv	Completions: Attach wellbore diagram of Spot 25 st Curit@ 8890 DV/Tool Peet)
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ The Oil Conserv 24 hours prior to	Completions: Attach wellbore diagram of Spot 25=* Court@8990 DV/Tool Peet) Vation Division Must be notified
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ Spud Date: Rig Relea	Completions: Attach wellbore diagram of spot 25 = x Contenderse 8890 DV/7000 Feet) vation Division Must be notified to the beginning of plugging operations.
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ The Oil Conserv 24 hours prior to	Completions: Attach wellbore diagram of spot 25 = x Contenderse 8890 DV/7000 Feet) vation Division Must be notified to the beginning of plugging operations.
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of MI x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ Spud Date: The Oil Conservation Rig Relea The oil Conservation Rig Relea The oil conservation Rig Relea The oil conservation Spud Date: The Oil Conservation Spud Date: Cut off what the information above is true and complete to the best of my knowled Cut of the plug the top the top the best of my knowled Cut of the plug the top the top the best of the top the best of the top the top the best of the top the	Completions: Attach wellbore diagram of Spot 25=* Comt@ 8390 Comt@ 83900 Comt@ 8390 C
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of M1 x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ Spud Date: Rig Relez The Oil Conservation Spud Date: I hereby certify that the information above is true and complete to the best of my knowled SIGNATURE MARAMAN TITLE Cogent	Completions: Attach wellbore diagram of Spot 25 = x Contenderson 2890 DV/7000 Feet) vation Division Must be notified to the beginning of plugging operations. dge and belief. <u>DATE</u> $5/20/13$
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of M1 x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet - Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ Spud Date: I hereby certify that the information above is true and complete to the best of my knowle	Completions: Attach wellbore diagram of $5pof 25 \le r$ Comta 8890 DV/7000 Feet) V ation Division Must be notified to the beginning of plugging operations. dge and belief. DATE 5/20/13
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of M1 x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet – Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ Spud Date: I hereby certify that the information above is true and complete to the best of my knowle SIGNATURE SIGNATURE SIGNATURE M.M.M.Marcharyt For State Use Only	Completions: Attach wellbore diagram of Spot 25 = 4 Contar 8890 DV/7000 eet) vation Division Must be notified to the beginning of plugging operations. dge and belief. DATE 5/20/13 Or mocoi/PHONE(575) 492-1230
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of M1 x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermidiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet – Yates /Base of Salt 2453 feet Spot 25 sack cement plug 1320 feet – Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 25 sack cement plug at 400 feet (Fresh Water Plug) To Surface Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ The Oil Conserv 24 hours prior to Spud Date:	Completions: Attach wellbore diagram of Spot 25 = 4 Contar 8890 DV/7000 eet) vation Division Must be notified to the beginning of plugging operations. dge and belief. DATE 5/20/13 Or mocoi/PHONE(575) 492-1230
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple C proposed completion or recompletion. TLT SWD proposes to plug and abandon as follows Notify NMOCD District 1 of M1 x RU Tag CIBP set at 9400 feet, Spot 25 sx cement plug x WOC x Tag plug x Displace cas Spot 25 sack cement plug 6900 feet – Top of Tubb at 6845 feet Spot 25 sack cement plug 4550 feet – Intermdiate casing shoe at 4480 feet Spot 25 sack cement plug 2500 feet – Yates /Base of Salt 2453 feet Spot 60 sack cement plug 1320 feet - Anhy / Top of Salt / Surface casing shoe(809 f WOC x Tag Surface shoe plug at 759 feet or above Spot 10 sack surface plug Cut off well head, Install PA Marker x Prepare location for release Enclosed before and after well diagrams, C144 CLEZ Spud Date: I hereby certify that the information above is true and complete to the best of my knowle SIGNATURE SIGNATURE SIGNATURE M.M.M.Marcharyt For State Use Only	Completions: Attach wellbore diagram of Spot 25 = x Contenderson 2890 DV/7000 Feet) vation Division Must be notified to the beginning of plugging operations. dge and belief. <u>DATE</u> $5/20/13$



