Form 3160-5 (August 1999)

UNITED STATES

UNITED STATES

DEPARTMENT OF THE INTERIOR N. French Drive

BUREAU OF LAND MANAGEMENTODDS, NM 26249

5. Lease:

FORM APPROVED OMB No. 1004-0135 Expires November 30, 2000

## SUNDRY NOTICES AND REPORTS ON WELLS

5. Lease Serial No. LC064118

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.					6. If Indian, Allottee or Tribe Name			
SUBMIT IN TRIPLICATE - Other instructions on reverse side					7. If Unit or CA/Agreement, Name and/or No.			
1. Type of Well  ☑ Oil Well ☐ Gas Well ☐ Other					8. Well Name and No.  E C HILL B FEDERAL #016			
2. Name of Operator Latigo Petroleum, Inc.					9. API Well No.			
3a. Address 3b. Phone No. (432)684-429				ı code )	10. Field a	-025-33476 Field and Pool, or Exploratory Area		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 330' FSL & 950' FEL SEC 34(P) T23S, R37E					TEAGUE; PADDOCK-BLINEBRY  11. County or Parish, State LEA NM			
12. CHECK AP	PROPRIATE BOX(ES) T	O INDICATE	NATURE C	F NOTICE, R	EPORT, O	R OTHER DATA		
TYPE OF SUBMISSION TYPE OF ACTION								
<ul><li>Notice of Intent</li><li>Subsequent Report</li><li>☐ Final Abandonment Notice</li></ul>	Acidize  Alter Casing  Casing Repair  Change Plans  Convert to Injection	Deepen Fracture Tr New Const Plug and A Plug Back	ruction 🖾	Production (Star Reclamation Recomplete Temporarily Ab Water Disposal		Water Shut-Off Well Integrity Other ADD NEW	PERFS	
Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent ports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new invokal, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed; and the operation has determined that the site is ready for final inspection.)  1) RUPU. Kill well w/ 2% KCI. POH w/ rods & pump. NU BOP. POH w/ tubing.  2) RU wireline. RIH w/ casing gun, perforate 5093-97', 5100-10', 5114-5124', and 5126-42' w/ 4 jspf (160 holes total). RD wireline.  3) RIH w 5 ½" RBP w/ ball catcher and packer, set RBP @ +5200'. Set pkr @ 5190', test RBP to 1000#. Unset pkr, spot 150 gals 15% NEFE @ +5142'. Pull packer to +5043', reverse acid into tubing, and set packer. Test casing-tubing annulus to 500#. Put acid away. Swab and test Paddock 5093-5142'.  4) RU acidizers. Acidize w/ 3500 gals 15% NEFE and 320 1.1 SG RCNBs. Swab back load and test.  5) Unset pkr, POH.								
6) RIH w/ tubing, rods, and pump. Hang well on.					AG	DDOWET		
Sabra Woody				ng Techniciar	OCT 1 1 2005			
Signature — /// / / / / / / / / / / / / / / / /			Date 09/28/200	5				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE PETROLEUM ENGINEER								
Approved by			Title			Date		
Conditions of approval, if any, are certify that the applicant holds leg which would entitle the applicant	al or equitable title to those rigi			;				

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.