

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 87240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-25171
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: ARES STATE
8. Well Number 4
9. OGRID Number 148381
10. Pool name or Wildcat JALMAT; TAN. YATES, 7-RVRS 33820

Pit or Below-grade Tank Application ☐ or Closure ☐
Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____
Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other	2. Name of Operator MISSION RESOURCES CORPORATION
3. Address of Operator 1100 LOUISIANA, STE. 1455 HOUSTON, TX 77002	4. Well Location Unit Letter <u>G</u> : <u>1650</u> feet from the <u>NORTH</u> line and <u>1980</u> feet from the <u>EAST</u> line Section <u>16</u> Township <u>23S</u> Range <u>36E</u> NMPM County <u>LEA</u>
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3495' DF	

12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPLETION <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

See attached for Procedure and Wellbore Schematic to Plug and Abandon Well.

**THE OIL CONSERVATION DIVISION MUST
BE NOTIFIED 24 HOURS PRIOR TO THE
BEGINNING OF PLUGGING OPERATIONS.**

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐ , a general permit ☐ or an (attached) alternative OCD-approved plan ☐

SIGNATURE _____ TITLE Regulatory Coordinator DATE _____

Type or print name Valorie J. Garza

E-mail address: _____

Telephone No. 832-369-2125

For State Use Only

APPROVED BY GARY W. WINK TITLE _____ DATE NOV 17 2005

Conditions of Approval, if any: _____

FIELD REPRESENTATIVE II/STAFF MANAGER

Mission Resources Corp.
Ares State #4
Jalmat Field
Lea County, NM
November 8, 2005

Plugging and Abandonment Procedure

1. MIRU work over rig. Kill well. Install BPV. ND tree. NU BOP's.
2. POOH with tubing.
3. RU EL. Run GR/junk basket to 3315'±. Set CIBP @ 3300'±. Dump bail cement on top of CIBP. Test casing to 500 psi..
4. TIH with workstring. Load hole with gelled 10# brine.
5. Mix and spot 200' cement plug from 2880-3080' (base of salt @ 2980').
6. Mix and spot 200' cement plug from 1480-1680' (top of salt @ 1580').
7. Perforate 5-1/2" casing at 450'.
8. Squeeze perfs @ 345' and circulate to surface with 150 sxs cement.
9. Cut off wellhead – weld on P&A marker.
10. Clean off location for OCD inspection.

1710'-1610' PERF + SQZ.
TAG
T.O.C. 1660'

