Submit 3 Copies To Appropriate District State of New Mexico Form C-103 Office Energy, Minerals and Natural Resources May 27, 2004 District I WELL API NO. 1625 N. French Dr., Hobbs, NM 87240 30-025-36083 District II OIL CONSERVATION DIVISION 1301 W. Grand Ave., Artesia, NM 88210 5. Indicate Type of Lease 1220 South St. Francis Dr. District III STATE X FEE \square 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 District IV 6. State Oil & Gas Lease No. 1220 S. St. Francis Dr., Santa Fe, NM 87505 30950 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name: (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A Amerada State DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 8. Well Number 1. Type of Well: Oil Well X Gas Well Other 2. Name of Operator 9. OGRID Number **Energen Resources Corporation** 162928 3. Address of Operator 10. Pool name or Wildcat 3300 N. "A" St., Bldg 4, Ste, 100, Midland, TX 79705 Saunders. San Andres 4. Well Location 990 330 feet from the ___ South West Unit Letter ___ line and feet from the line Township 15-S Range 33-E **NMPM** County Lea 11. Elevation (Show whether DR, RKB, RT, GR, etc.) 4212' GL Pit or Below-grade Tank Application or Closure __ Depth to Groundwater _____ Distance from nearest fresh water well ___ __ Distance from nearest surface water Pit Liner Thickness: _bbls; Construction Material Below-Grade Tank: Volume_ 12. Check Appropriate Box to Indicate Nature of Notice, Report, or Othe Sata NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON ALTERING CASING [REMEDIAL WORK PĽÚĞ ÂND **TEMPORARILY ABANDON** \square CHANGE PLANS COMMENCE DRILLING OPNS. ABANDONMENT PULL OR ALTER CASING CASING TEST AND **MULTIPLE** COMPLETION **CEMENT JOB** OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. 1. MIRU pulling unit. Install BOPE. 3. RIH w/CIBP and tubing. Set CIBP @ 4730', tag. Circulate hole w/treated 2% KCl water. Pressure test casing to 500 psig. POOH and lay down tubing. 4. Load casing w/treated 2% KCl water. 5. Notify NMOCD and perform MIT to 500 psig. I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/ | | lbe constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan Regulatory Analyst SIGNATURE \ _TITLE___ E-mail address: clarson@energen.com Type or print name Carolyn Larson Telephone No. 432 684-3693 LLANCE DE DISTRICTE SUPERVISOR/GENERAL MANAGER For State Use Only APPROVED BY

Conditions of Approval, if any: