



**Tres Papalotes 4-3**  
**Lea County, New Mexico**  
**TA Procedure**

**February 9, 2006**

1. MIRU PU. NU BOP. Release packer. POH w/ 2 7/8" tbg.
2. RU Wireline Co. Set CIBP @ 10,400'. Tag CIBP w/ wireline. Bail <sup>35'</sup>~~25'~~ of cement on top of CIBP. Rig down Wireline Co.
3. Pressure test casing to <sup>500#</sup>~~300~~ psi for 30 min.
4. Rig down.