

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.

FORM APPROVED
OMB No. 1004-0117
Expires: March 31, 2007

SUBMIT IN TRIPLICATE- Other instructions on reverse side.

1. Type of Well ☐ Oil Well ☐ Gas Well ☒ Other State Well

2. Name of Operator LATIGO PETROLEUM, INC.

3a. Address Midland, TX 79701
550 W. Texas, Suite 700, TX 79701

3b. Phone No. (include area code) (432) 684-4293

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)
990' FNL & 990' FEL
Sec. 35 (A), T7S, R35E

5. Lease Serial No.

6. If Indian, Allottee or Tribe Name

7. If Unit or CA/Agreement, Name and/or No.
8910195820 Todd Lower San Andres

8. Well Name and No.
Todd Lower San Andres Unit #3501

9. API Well No.
30-041-10210

10. Field and Pool, or Exploratory Area
Todd Lower San Andres Assoc.

11. County or Parish, State
Roosevelt, NM

12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION	TYPE OF ACTION			
☐ Notice of Intent	☐ Acidize	☐ Deepen	☐ Production (Start/Resume)	☐ Water Shut Off
☒ Subsequent Report	☐ Alter Casing	☐ Fracture Treat	☐ Reclamation	☐ Well Isolation
☐ Final Abandonment Notice	☐ Casing Repair	☐ New Construction	☐ Recomplete	☐ Other
	☐ Change Plans	☒ Plug and Abandon	☐ Temporarily Abandon	
	☐ Convert to Injection	☐ Plug Back	☐ Water Disposal	

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

- 2-1-06 Notify B.L.M., Alexis Swoboda & N.M. O.C.D., E. Gonzales. 2-2-06 Load 2 7/8" csg. with 10# M.L.F. Set 2 7/8" C.I.B.P. @4,100'. Dump bail 1 1/2" sx. cmt. 4,100'-4,039'. Dump bail 1 1/2" sx. cmt. 2,160'-2,100'.
- 2-3-06 Unable to pull 2 7/8" csg. from 2,100'. Consulted w/O.C.D. Johnny Robinson. Cut 2 7/8" csg. @2,100'. Mix & sqz. 25 sx. cmt. down 2 7/8" csg. @ 2 bbl/min @1000 psi. Dis T.O.C. to 2,000'. S.I.P. @ 700 psi.
- 2-6-06 Tag T.O.C. @2,033'. Perforate 2 7/8" csg. @1,242'. Sqz. 25 sx. cmt. w/2% CaCl. @ 2 bbl/min. @800 psi. Dis T.O.C. to 1,142'. S.I.P. @ 500 psi. W.O.C. - tag T.O.C. @1,120'. Perf. @400'. Establish P.I.R. & commun. out 2 7/8" x 7" csg. Consult OCD Johnny Robinson. Pump 65 sx. cmt. down 2 7/8" csg. out annulus. Started pressure up to 1,200 p.s.i. and lost circulation at end of plug. Dis T.O.C. to 60'. S.I.P. 1,100 p.s.i. (over on back)

14. I hereby certify that the foregoing is true and correct
Name (Printed/Typed)

Signature: ROGER MASSEY Title: AREA MANAGER

Date: 2-10-06

THIS SPACE FOR FEDERAL OR STATE OFFICE USE

Approved by: [Signature] Title: Date:

Conditions of Approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would enable the applicant to conduct operations thereon.

Office:

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

GWW

AP

2-7-06 Pressure test 2 7/8" and 7" casings to 1,500 p.s.i. Pressure held. Tag T.O.C. @63'. Consult with N.M. O.C.D., Johnny Robinson. Perforate 2 7/8" csg. @63'. Mix & pump 15 sx. cmt. down 2 7/8" csg. thru perms. @63' with cement. Circulated to surface out 2 7/8" X 7" annulus. Leave all casings full of cement. Cut W.H. and anchors. Install P & A marker. Backfill collar.