

District I
1625 N. French Dr., Hobbs, NM 88240
Phone: (575) 393-6161 Fax: (575) 393-0720

State of New Mexico
Energy, Minerals and Natural Resources Department
Oil Conservation Division Hobbs District Office

BRADENHEAD TEST REPORT

Operator Name Seely Oil Company		API Number 30025016360000	
Property Name EK Penrose Sand Unit		Well No. 127	

Surface Location									
UL - Lot	Section	Township	Range		Feet from	N/S Line	Feet From	E/W Line	County
O	24	18S	34E		990	S	1980	E	Lea

Well Status									
TA'D WELL YES	NO	YES	SHUT-IN NO	INJECTOR INJ	SWD	PRODUCER OIL	GAS	DATE 9-12-19	

OBSERVED DATA

	(A)Surface	(B)Interm(1)	(C)Interm(2)	(D)Prod Casing	(E)Tubing
Pressure	0	N/A	N/A	0	0
Flow Characteristics					
Pull	Y/N	Y/N	Y/N	Y/N	CO2 —
Steady Flow	Y/N	Y/N	Y/N	Y/N	WTR —
Surges	Y/N	Y/N	Y/N	Y/N	GAS —
Down to nothing	Y/N	Y/N	Y/N	Y/N	Type of Fluid
Gas or Oil	Y/N	Y/N	Y/N	Y/N	Injected for
Water	Y/N	Y/N	Y/N	Y/N	Waterflood if
					applies

Remarks - Please state for each string (A,B,C,D,E) pertinent information regarding bleed down or continuous build up if applies.

Well SI. inj. line repairs

HOBBS ODD

SEP 19 2019

RECEIVED

Signature: Mike Frazier		OIL CONSERVATION DIVISION	
Printed name: Mike Frazier		Entered into RBDMS	
Title: Pumper		Re-test	
E-mail Address: nitro mikey @ mywdo.com			
Date:	Phone:		
Witness: Shay Holman			

INSTRUCTIONS ON BACK OF THIS FORM

PERFORMING BRADENHEAD TEST

General Procedure for Bradenhead Test

Identify: All valves prior to testing

Gauges: Install on each casing string to record pressure.

Assure: That all valves are in good working condition and closed at least 24 hours prior to testing.

Open: Each valve (Bradenhead, intermediate and casing valves) is to be opened separately.

Check Gauges: Record pressure on each gauge and casing string on BHT form. Open valves to atmosphere and record results on BHT form.

Designate what applies to the result of opening the valves for each string:

- | | |
|------------------------|-----------|
| • Blow or Puff | Yes or No |
| • Bled down to Nothing | Yes or No |
| • Steady Flow | Yes or No |
| • Oil or Gas | Yes or No |
| • Water | Yes or No |

Start: Injection or SWD pump so tubing pressure can be read.

Instructions below apply to the District 1 Hobbs office since this must be reported on a form.

In case of pressure:

1. Record pressure reading on gauge.
2. Bleed and note time elapsed to bleed down.
3. Leave valve open for additional observation.
4. Note any fluids expelled.

In absence of Pressure:

1. Leave valve open for additional observation.
2. Note types of fluids expelled.
3. Note if fluids persist throughout test.

Note: Tubing pressure on injection or SWD wells.

Test will be signed by person performing test with a contact phone number.