	State of New Mexico	Form C-102
District I	linerals and Natural Resources	Revised March 25, 1999 WELL API NO.
1625 N. French Dr., Hobbs, NM 87240 District II OII CO		30-025-02242
District II       OIL CONSERVATION DIVISION         811 South First, Artesia, NM 87210       2040 South Pacheco         District III       2040 South Pacheco         1000 Rio Brazos Rd., Aztec, NM 87410       Santa Fe, NM 87505		5. Indicate Type of Lease
		STATE 🕱 FEE 🗆
District IV.	Sana 1 0, 1414 07505	6. State Oil & Gas Lease No.
2040 South Pacheco, Santa Fe, NM 87505		857943
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well X Gas Well Other		7. Lease Name or Unit Agreement Name: OA Central Vacuum Unit
Name of Operator		8. Well No.
2. Name of Operator 3. Address of Operator 15 Smith Road - Midland, Texas 79705		92
		9. Pool name or Wildcat
		Vacuum Grayburg San Andres
Section 36 Tow	t from the <u>South</u> line and wnship 17–s Range 34– on <i>(Show whether DR, RKB, RT, C</i>	E NMPM County Lea
	3991' GL	
11. Check Appropriate	Box to Indicate <sub>l</sub> Nature of No	tice, Report, or Other Data
NOTICE OF INTENTION TO	D:   9	SUBSEQUENT REPORT OF:
ERFORM REMEDIAL WORK 🔲 PLUG AND .	ABANDON 🔲 REMEDIAL WO	ORK I ALTERING CASING
		RILLING OPNS. 🔲 PLUG AND
		ABANDONMENT
JLL OR ALTER CASING L MULTIPLE COMPLETI	ON CASING TEST CEMENT JOB	
THER:		Pump Short Down Hole; Acidize; Squeeze
<ol> <li>Describe Proposed or Completed Operations ( of starting any proposed work). SEE RULE 1.</li> </ol>		
or recompilation. 09-04-02 MIRU. TOH w/2-3/8" they & a		attach wellbore diagram of proposed completion
09–04–02 MIRU. TOH w/2–3/8" tbg & s cable head cracked. TIH w/	sub pump. Shaft broke off so /2-3/8" tbg for kill string.	sparator & scale on bottom of pump; also
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r	sub pump. Shaft broke off so /2-3/8" tbg for kill string.	
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'.	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal	sparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/h set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gai gals TH-756 mixed w/FW. Re	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/ set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re bg to 3038' for kill string.	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg;
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/h set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re bg to 3038' for kill string.	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg;
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'.	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re bg to 3038' for kill string.	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg;
<ul> <li>09-04-02 MIRU. TOH w/2-3/8" tbg &amp; s cable head cracked. TIH w/</li> <li>09-05-02 TOH w/kill string. TIH w/r set @ 4044'.</li> <li>09-06-02 Acidize Grayburg San Andres</li> <li>09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th</li> <li>09-10-02 TIH w/2-3/8" tbg to 4472'. Test run.</li> </ul>	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re bg to 3038' for kill string.	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg; QCI well head & landed tbg, Start sub.
<ul> <li>09-04-02 MIRU. TOH w/2-3/8" tbg &amp; s cable head cracked. TIH w/</li> <li>09-05-02 TOH w/kill string. TIH w/r set @ 4044'.</li> <li>09-06-02 Acidize Grayburg San Andres</li> <li>09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th</li> <li>09-10-02 TIH w/2-3/8" tbg to 4472'. Test run.</li> </ul>	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re bg to 3038' for kill string.	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg; QCI well head & landed tbg, Start sub.
<ul> <li>09-04-02 MIRU. TOH w/2-3/8" tbg &amp; s cable head cracked. TIH w/</li> <li>09-05-02 TOH w/kill string. TIH w/r set @ 4044'.</li> <li>09-06-02 Acidize Grayburg San Andres</li> <li>09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th</li> <li>09-10-02 TIH w/2-3/8" tbg to 4472'. Test run.</li> </ul>	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re bg to 3038' for kill string.	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg;
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'. Test run. 09-11-02 RD. FINAL REPORT.	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gai gals TH-756 mixed w/FW. Re bg to 3038' for kill string. TIH w/sub pump. Assemble (	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg; QCI well head & landed tbg, Start sub.
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'. Test run. 09-11-02 RD. FINAL REPORT.	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gai gals TH-756 mixed w/FW. Re bg to 3038' for kill string. TIH w/sub pump. Assemble (	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg; QCI well head & landed tbg, Start sub.
09-04-02 MIRU. TOH w/2-3/8" tbg & a cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/k set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'. Test run. 09-11-02 RD. FINAL REPORT.	sub pump. Shaft broke off so /2-3/8" tbg for kill string. bit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gai gals TH-756 mixed w/FW. Re bg to 3038' for kill string. TIH w/sub pump. Assemble (	eparator & scale on bottom of pump; also w/tbg & bit. TIH w/packer & tbg; packer ls 80/20 DAD acid. l packer & TOH w/tbg. TIH w/pit & tbg; QCI well head & landed tbg, 'Start sub. Cost of the start sub.
09-04-02 MIRU. TOH w/2-3/8" tbg & a cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'. Test run. 09-11-02 RD. FINAL REPORT.	sub pump. Shaft broke off so /2-3/8" tbg for kill string. oit & tbg; tag @ 4710'. TOH s from 4096'-4710' w/4000 gal gals TH-756 mixed w/FW. Re og to 3038' for kill string. TIH w/sub pump. Assemble (	sparator & scale on bottom of pump; also w/thg & bit. TIH w/packer & thg; packer ls 80/20 DAD acid l packer & TOH w/thg. TIH w/bit & thg; QCI well head & landed thg, Start sub Compared to the start sub belief. Specialist
09-04-02 MIRU. TOH w/2-3/8" tbg & a cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'. Test run. 09-11-02 RD. FINAL REPORT. ereby certify that the information above is true and com GNATURE Sum Manuelland	sub pump. Shaft broke off so /2-3/8" the for kill string. bit & the; tag @ 4710'. TOH s from 4096'-4710' w/4000 gai gals TH-756 mixed w/FW. Rei beg to 3038' for kill string. TIH w/sub pump. Assemble ( mplete to the best of my knowledge and <u>TITLE Regulatory</u>	eparator & scale on bottom of pump; also w/thg & bit. TIH w/packer & thg; packer ls 80/20 DAD acid. l packer & TOH w/thg. TIH w/pit & thg; QCI well head & landed thg, Start sub. CI well head & landed thg, Start sub. belief. Specialist
09-04-02 MIRU. TOH w/2-3/8" tbg & s cable head cracked. TIH w/ 09-05-02 TOH w/kill string. TIH w/r set @ 4044'. 09-06-02 Acidize Grayburg San Andres 09-09-02 Swab. Scale squeeze w/275 tag fill @ 4675'. TOH w/th 09-10-02 TIH w/2-3/8" tbg to 4472'. Test run. 09-11-02 RD. FINAL REPORT.	sub pump. Shaft broke off so /2-3/8" the for kill string. bit & the; tag @ 4710'. TOH s from 4096'-4710' w/4000 gai gals TH-756 mixed w/FW. Rei beg to 3038' for kill string. TIH w/sub pump. Assemble ( mplete to the best of my knowledge and <u>TITLE Regulatory</u>	sparator & scale on bottom of pump; also w/thg & bit. TIH w/packer & thg; packer ls 80/20 DAD acid. l packer & TOH w/thg. TIH w/bit & thg; QCI well head & landed thg, Start sub. Construction of pump; also belief. Specialist