Do not use a abandoned w	vell. Use Form 3160-3 (RIPLICATE- Other inst Gas Well Other ST ROYALTIES, INC. MIDLAND, TX 79705 , T., R., M., or Survey Description)	E INTERIOR VAGEMENT	FORM APPROVED OM B No. 1004-0137 Expires: March 31, 2007 5. Lease Serial No. LC030168A 6. If Indian, Allottee or Tribe Name 7. If Unit or CA/Agreement, Name and/or No. 8. Well Name and No. EAVES A #10 9. API Well No. 30-025-12014 10. Field and Pool, or Exploratory Area SCARBOROUGH; YATES 7 RIVERS 11. County or Parish, State
			LEA COUNTY, NM
TYPE OF SUBMISSION	PPROPRIATE BOX(ES) TO	INDICATE NATURE OF NOTICE TYPE OF ACTION	
If the proposal is to deepen dire Attach the Bond under which the following completion of the intresting has been completed. Find determined that the site is ready Notify the BLM 24 hrs print MI & RU WS. NU BOP. RIH & tag CIBP set @ 29. Pull tbg to 300' and spot 3 Spot 20 sx cmt 60' - 3'. RD PU; install dry hole matical states of the state of the states of the sta	ectionally or recomplete horizontally he work will be performed or provio volved operations. If the operation a nal Abandonment Notices shall be a / for final inspection.)	Fracture Treat Reclamatic New Construction Plug and Abandon Plug and Abandon Plug Back Water Disp nent details, including estimated starting data y, give subsurface locations and measured a de the Bond No. on file with BLM/BIA. Re results in a multiple completion or recompletion filed only after all requirements, including re procedures. APPROV GENERA	c Other
Schematic attached.		MIACH	ED ED
14. I hereby certify that the fore	going is true and correct		ED
		Title OPERATIONS A	
 14. I hereby certify that the foreg Name (Printed/Typed) 			
14. I hereby certify that the foreg Name (Printed/Typed) DAWN M. HOW	ARD	Title OPERATIONS A	SSISTANT 10/19/2006 CE USE OCT 2 1 2006



Notice of intent dated 1/29/01 shows Prod. Equip. pulled from well & CIBP was set (or to be set) @ 2920'

۱

SUNDRY NOTICE SPECIAL STIPULATIONS

- A. Approval is granted to P/A this well with the following modifications to the program:
- B. Tag the cement on top of the CIBP for the completion and the base of the salt.
- C. Set a 25 sack cement plug @ 1300' for the top of the salt and tag.
- D. Set a 25 sack plug @ 404' for the surface casing shoe.
- E. The surface cement plug must be at least 25 sacks,

<u>Engineering</u> can be reached at 505-706-2779 for any variances that might be necessary.

F Wright 10/25/06

.

4