	State of New Mex		Form C-10	
Office District I	Energy, Minerals and Natur	ral Resources	May 27, 200	04
1625 N. French Dr., Hobbs, NM 88240			WELL API NO.	
<u>District II</u> 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION	DIVISION	30-025-04657	
District III	1220 South St. Fran	icis Dr.	5. Indicate Type of Lease STATE X FEE	
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NM 87		6. State Oil & Gas Lease No.	
District IV	Banta 10, 19191 07	303	6. State Off & Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM 87505				
	ICES AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO DEEPEN OR PLU	JG BACK TO A		
	CATION FOR PERMIT" (FORM C-101) FO	OR SUCH	Eunice Monument South Unit	
PROPOSALS.)	Gas Well Other		8. Well Number 218	
1. Type of Well: Oil Well X	Gas well Other		9. OGRID Number 005380	-
2. Name of Operator			3. OGIND Number 003300	
XTO Energy Inc.			10. Pool name or Wildcat Eunice	_
3. Address of Operator 200 N. Loraine, Ste. 800 Midl	and TV 70701		Monument; Grayburg-San Andres	
	and, 17 /9/01		Trionament, Grayous San I maios	_
4. Well Location				
Unit LetterK_:	feet from theNorth	_ line and1980_	feet from theWestline	
Section 6 Tow	rnship 21S Range 36E	NMPM Lea		
	11. Elevation (Show whether DR,	RKB, RT, GR, etc.,)	
Pit or Below-grade Tank Application	or Closure			93
Pit typeDepth to Groundw	vater Distance from nearest fresh w	ater well Dist	tance from nearest surface water	
, , , ,			onstruction Material	
Pit Liner Thickness: mil				!
12. Check	Appropriate Box to Indicate Na	ature of Notice,	Report or Other Data	
NOTICE OF IN	NTENTION TO:		SEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON X REMEDIAL WOR				J ;
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DR	ILLING OPNS.□ P AND A □	
PULL OR ALTER CASING	MULTIPLE COMPL	CASING/CEMEN	T JOB 🔲	
				į
OTHER:		OTHER:]_!
13. Describe proposed or comp	pleted operations. (Clearly state all r	pertinent details, an	d give pertinent dates, including estimated of	late:
of starting any proposed w	and OFF DILLE 1102 For Multin			
	OIK). SEE KULE 1103. FOI MILIUP	le Completions: At	ttach wellbore diagram of proposed complet	ion
or recompletion.	ork). See Role 1103. For Munup.	le Completions: At	ttach wellbore diagram of proposed complet	ion
	ork). SEE ROLE 1103. For Municip.	le Completions: At	ttach wellbore diagram of proposed complet	ion
		le Completions: At	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'.	ug and abandon well.		ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'.			ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170	ug and abandon well. not 60 sx cement. PUH to ~3,050' and').	nd circulate clean.	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp	ug and abandon well. not 60 sx cement. PUH to ~3,050' and circul	nd circulate clean.	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sx 6. WOC & Tag TOC at ~2,40	ug and abandon well. not 60 sx cement. PUH to ~3,050' and circul oo'.	nd circulate clean.	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sx 6. WOC & Tag TOC at ~2,40	ug and abandon well. not 60 sx cement. PUH to ~3,050' and circul	nd circulate clean.	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sx 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and circul oo'. and BOP. Weld on pull nipple. ,300'.	nd circulate clean. late clean.	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupance. c cement. PUH to ~2,300' and circulation. oo'. and BOP. Weld on pull nipple. ,300'. to 1,350'. Spot 80 sx cement. PUH	nd circulate clean. late clean.	ttach wellbore diagram of proposed complet	ion
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100)	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation of the control of the cont	nd circulate clean. late clean. to ~850' and circu	tach wellbore diagram of proposed complete squared by the squared	10 10 112 13 14 15 15 15 15 15 15 15 15 15 15 15 15 15
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation of the control of the cont	nd circulate clean. late clean. to ~850' and circu	ttach wellbore diagram of proposed complet	10 10 112 13 14 15 15 15 15 15 15 15 15 15 15 15 15 15
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug.	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation. c cement. PUH to ~2,300' and circulation. and BOP. Weld on pull nipple. 300'. to 1,350'. Spot 80 sx cement. PUH o'') inside 9-5/8" casing from 400' to sur	nd circulate clean. late clean. to ~850' and circulate circulate clean.	tach wellbore diagram of proposed complete squared by the squared	10 10 112 13 14 15 15 15 15 15 15 15 15 15 15 15 15 15
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug.	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation of the control of the cont	nd circulate clean. late clean. to ~850' and circulate clean.	late clean. 5% excess so assume a total of ~125 sks for	101 12 13 14 15 the
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug.	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation. c cement. PUH to ~2,300' and circulation. and BOP. Weld on pull nipple. 300'. to 1,350'. Spot 80 sx cement. PUH o'') inside 9-5/8" casing from 400' to sur	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE	late clean. 5% excess so assume a total of ~125 sks for	the
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug.	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation. c cement. PUH to ~2,300' and circulation. and BOP. Weld on pull nipple. 300'. to 1,350'. Spot 80 sx cement. PUH o'') inside 9-5/8" casing from 400' to sur	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICATION DIVISION.	the
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug.	ug and abandon well. oot 60 sx cement. PUH to ~3,050' and occupation. c cement. PUH to ~2,300' and circulation. and BOP. Weld on pull nipple. 300'. to 1,350'. Spot 80 sx cement. PUH o'') inside 9-5/8" casing from 400' to sur	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICATION DIVISION.	the
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anche	oug and abandon well. oot 60 sx cement. PUH to ~3,050' and original of the control of the contr	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE BEG	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICE TO SINNING OF PLUGGING OPERA	the
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anche	oug and abandon well. oot 60 sx cement. PUH to ~3,050' and original of the control of the contr	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE BEG BEG	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICE INNING OF PLUGGING OPERATE and belief. I further certify that any pit or below the complete that the complete t	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anche	oug and abandon well. oot 60 sx cement. PUH to ~3,050' and original of the control of the contr	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE BEG BEG	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICE TO SINNING OF PLUGGING OPERA	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sp 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anchord	oug and abandon well. oot 60 sx cement. PUH to ~3,050' and original of the control of the contr	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE BEG est of my knowledg , a general permit	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICAL INNING OF PLUGGING OPERATE and belief. I further certify that any pit or belong an (attached) alternative OCD-approved plan	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anchorded tank has been/will be constructed of	ug and abandon well. bot 60 sx cement. PUH to ~3,050' and o'). c cement. PUH to ~2,300' and circul oo'. and BOP. Weld on pull nipple. ,300'. to 1,350'. Spot 80 sx cement. PUH b') inside 9-5/8" casing from 400' to sur ors, install dryhole marker, and clear above is true and complete to the ber closed according to NMOCD guidelines	nd circulate clean. late clean. to ~850' and circulate clean. rface, 116 sks plus n location. THE BE BEG est of my knowledg , a general permit	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICAL INNING OF PLUGGING OPERATE and belief. I further certify that any pit or belong an (attached) alternative OCD-approved plan	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 ss 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anchor	ug and abandon well. bot 60 sx cement. PUH to ~3,050' and or	nd circulate clean. late clean. to ~850' and circulate and circulate clean. to ~850' and circulate	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICE INNING OF PLUGGING OPERATE and belief. I further certify that any pit or below of an (attached) alternative OCD-approved plan [12]	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sx 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anchor grade tank has been/will be constructed of SIGNATURE Type or print name Kristy Ward	ug and abandon well. bot 60 sx cement. PUH to ~3,050' and original origina	nd circulate clean. late clean. to ~850' and circulate and circulate clean. to ~850' and circulate	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICAL INNING OF PLUGGING OPERATE and belief. I further certify that any pit or below of an (attached) alternative OCD-approved plan [12/12/06] Telephone No. 432-620-6740	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sx 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anchor grade tank has been/will be constructed of SIGNATURE Type or print name Kristy Ward	ug and abandon well. bot 60 sx cement. PUH to ~3,050' and original origina	nd circulate clean. late clean. to ~850' and circulate and circulate clean. to ~850' and circulate	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICAL INNING OF PLUGGING OPERATE and belief. I further certify that any pit or below of an (attached) alternative OCD-approved plan [12/12/06] Telephone No. 432-620-6740	the TICNS.
or recompletion. 1. Notify OCD of intent to pl 2. Tag CIBP @ 3,780'. 3. Circulate 9.0 ppg mud. Sp 4. WOC & Tag TOC (~3,170 5. PUH to 2,665'. Spot 40 sx 6. WOC & Tag TOC at ~2,40 7. POOH with tbg. ND WH 8. Cut and pull 7" casing at 1 9. RIH w/ 2-7/8" workstring 10. WOC & Tag TOC (~1,100 11. PUH to 400'. Fill cement surface plug. 12. Cut off wellhead and anchor grade tank has been/will be constructed of SIGNATURE Type or print name Kristy Ward	ug and abandon well. bot 60 sx cement. PUH to ~3,050' and o'). c cement. PUH to ~2,300' and circul 00'. and BOP. Weld on pull nipple. ,300'. to 1,350'. Spot 80 sx cement. PUH D') inside 9-5/8" casing from 400' to sur ors, install dryhole marker, and clear above is true and complete to the ber closed according to NMOCD guidelines [TITLE	nd circulate clean. late clean. to ~850' and circulate and circulate clean. to ~850' and circulate	late clean. 5% excess so assume a total of ~125 sks for NOTIFIED 24 HOURS PRICAL INNING OF PLUGGING OPERATE and belief. I further certify that any pit or below of an (attached) alternative OCD-approved plan [12/12/06] Telephone No. 432-620-6740	the TICNS.