Office		New Mexico	Form C-103
DISTRICT I			Revised March 25, 199
1625 N. French Dr., Hobbs NM 88240	Chergy, willierals a	and Natural Resources	WELL API NO.
DISTRICT II 1301 W. Grand Avenue, Artesia NM 88210	OIL CONSER\	VATION DIVISION	30-025-35899
DISTRICT III		St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec NM 87410	Santa Fe. New	Mexico 87504-2088	STATE FEE X
DISTRICT IV	Santa i S, NSW	WEXIEC 67 004-2000	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505			or state on a sac mease its.
SU	NDRY NOTICES AND REPORTS	ON WELLS	7. Lease Name or Unit Agreement Name
	OPOSALS TO DRILL OR TO DEEPEN		<b>3</b>
	PPLICATION FOR PERMIT" (FORM C-	101) FOR SUCH	
PROPOSALS.)			Manadata a DAM
1. Type of Well:	<u></u>		Mamalotes BAM
Oil Well Gas Well	X Other		
2. Name of Operator			8. Well No.
	es Petroleum Corporation	n	1
3. Address of Operator			9. Pool Name or Wildcat
105	South 4th Str., Artesia, I	NM 88210	Morton Morrow (Gas)
4. Well Location			
Unit Letter P: 825	feet from the South	line and 1275	feet from the East line
			<u> </u>
Section 36	Township 14S Range	34E NMPM	County Lea
10. E	Elevation (Show whether DF, RK	B, RT, GR, etc.)	Company of Salary of Salar
Tori Name	4060' GR		
11. Check Appropriate Bo	x to Indicate Nature of Notic	e, Report, or Other Data	
	NTENTION TO:	SUBSEQUENT	REPORT OF
PERFORM REMEDIAL WORK	PLUG AND ABANDON	ļ	_
PERFORM REWEDIAL WORK	PLOG AND ABANDON	REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLING OPNS.	PLUG AND ABANDONMENT
PULL OR ALTER CASING	MULTIPLE	CASING TEST AND CEMENT JOB	
	COMPLETION		
OTHER:		OTHER: Completion	Operations X
		***************************************	
	eted operations. (Clearly state all	pertinent details, and give pertinent date	s. including estimated date
12. Describe proposed or comple		pertinent details, and give pertinent date Completions: Attach wellbore diagram	
12. Describe proposed or comple of starting any proposed wor		pertinent details, and give pertinent date Completions: Attach wellbore diagram	
12. Describe proposed or comple			
12. Describe proposed or complete of starting any proposed work or recompilation.	rk). SEE RULE 1103. For Multiple	Completions: Attach wellbore diagram	of proposed completion
Describe proposed or complete of starting any proposed work or recompilation.      Perforated M.	rk). SEE RULE 1103. For Multiple		of proposed completion
12. Describe proposed or complete of starting any proposed work or recompilation.	rk). SEE RULE 1103. For Multiple	Completions: Attach wellbore diagram	of proposed completion
Describe proposed or complete of starting any proposed work or recompilation.      Perforated M.	rk). SEE RULE 1103. For Multiple	Completions: Attach wellbore diagram	of proposed completion
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated Manual Interprop.	rk). SEE RULE 1103. For Multiple orrow 13262-13274' w/72	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b	of proposed completion inary foam w/21000# 20/40
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of	rk). SEE RULE 1103. For Multiple for the second sec	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced	inary foam w/21000# 20/40 casing and tied back to surface
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of	rk). SEE RULE 1103. For Multiple for row 13262-13274' w/72 collapsed. Cut and pulled	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced	inary foam w/21000# 20/40 casing and tied back to surface
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" complete or c	rk). SEE RULE 1103. For Multiple for row 13262-13274' w/72 collapsed. Cut and pulled apposite plug @ 13250'. S	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" complete or c	rk). SEE RULE 1103. For Multiple for row 13262-13274' w/72 collapsed. Cut and pulled apposite plug @ 13250'. S	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx.  and 4-1/2" 7560' (CFO).
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" complete or c	rk). SEE RULE 1103. For Multiple for row 13262-13274' w/72 collapsed. Cut and pulled apposite plug @ 13250'. S	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" complete or c	collapsed. Cut and pulled posite plug @ 13250'. See RULE 1103. For Multiple with the collapsed of the collapsed of the collapsed of the collapsed of the collapse of the colla	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx.  and 4-1/2" 7560' (CFO).
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting of the starting and the starting of	collapsed. Cut and pulled posite plug @ 13250'. See RULE 1103. For Multiple with the collapsed of the collapsed of the collapsed of the collapsed of the collapse of the colla	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting of the starting and the starting of	collapsed. Cut and pulled posite plug @ 13250'. See RULE 1103. For Multiple with the collapsed of the collapsed of the collapsed of the collapsed of the collapse of the colla	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting of the starting and the starting of	collapsed. Cut and pulled posite plug @ 13250'. See RULE 1103. For Multiple with the collapsed of the collapsed of the collapsed of the collapsed of the collapse of the colla	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting of the starting and certain and	collapsed. Cut and pulled posite plug @ 13250'. See RULE 1103. For Multiple with the collapsed of the collapsed of the collapsed of the collapsed of the collapse of the colla	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting of the starting and certain and	collapsed. Cut and pulled posite plug @ 13250'. See RULE 1103. For Multiple with the collapsed of the collapsed of the collapsed of the collapsed of the collapse of the colla	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" compriled retainer and certical proposed work of the proposed or complete work of the proposed or complete work of the proposed or complete work of the proposed wo	collapsed. Cut and pulled apposite plug @ 13250'. Spent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  holes. Frac'd w/34000 gal b  4-1/2" from 10894'. Spliced  set 4-1/2" cement retainer @ free plug @ 13250'. TOC behir	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" compriled retainer and certical proposed work of the proposed or complete work of the proposed or complete work of the proposed or complete work of the proposed wo	collapsed. Cut and pulled apposite plug @ 13250'. Spent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  4 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 2	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and sumped 310 sx.  and 4-1/2" 7560' (CHO.
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of 9-22-03 Set 4-1/2" compriled retainer and certical proposed work of the proposed or complete work of the proposed or complete work of the proposed or complete work of the proposed wo	collapsed. Cut and pulled apposite plug @ 13250'. Spent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  3 4-1/2" from 10894'. Spliced  5et 4-1/2" cement retainer @ 7  te plug @ 13250'. TOC behir	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx. and 4-1/2" 7560' (CFO).  7500' 100
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting and	collapsed. Cut and pulled apposite plug @ 13250'. Shent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  holes. Frac'd w/34000 gal b  4-1/2" from 10894'. Spliced  fet 4-1/2" cement retainer @ 7  te plug @ 13250'. TOC behir	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx. and 4-1/2" 7560' (CFO).  20/21/28/29/30/37 20/21/20  DATE 10/9/03
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting and	collapsed. Cut and pulled apposite plug @ 13250'. Spent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  holes. Frac'd w/34000 gal b  4-1/2" from 10894'. Spliced  fet 4-1/2" cement retainer @ 7  te plug @ 13250'. TOC behir	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx. and 4-1/2" 7560' (Chip).  20/21/28/29/30/37  7560' (Chip).  20/21/28/29/30/37  20/21/20  20/21/20
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting and	collapsed. Cut and pulled apposite plug @ 13250'. Spent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  2 holes. Frac'd w/34000 gal b  3 4-1/2" from 10894'. Spliced  3 et 4-1/2" cement retainer @ free free free free free free free	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx.  and 4-1/2" 7560' (CFO).  CONTINUE TO SURFACE.  10/9/03  Telephone No. 505-748-1471
12. Describe proposed or complete of starting any proposed work or recompilation.  12-18-02 Perforated M Interprop.  7-22-03 4-1/2" casing of the starting and	collapsed. Cut and pulled apposite plug @ 13250'. Spent. Drilled out composite packer @ 13150'.	Completions: Attach wellbore diagram  Choles. Frac'd w/34000 gal b  4-1/2" from 10894'. Spliced  Set 4-1/2" cement retainer @ fet plug @ 13250'. TOC behing  The best of my knowledge and belief.  Regulatory Compliance Technology  C DISTRICT SUPERVISOR/GENER	inary foam w/21000# 20/40  casing and tied back to surface.  11000' and pumped 310 sx.  and 4-1/2" 7560' (CFO).  CONTINUE TO SURFACE.  10/9/03  Telephone No. 505-748-1471